



WISNAP WI-FI/SERIAL ADAPTER

802.11 B/G Wireless LAN Module

User Manual and Command Reference

Version 4.41

May 28, 2015

1	Overview	4
2	Hardware Interface	4
2.1	Power	4
2.2	Reset	5
2.3	UART	5
2.4	Status Indicators	6
2.5	WiSnap M1 External Antenna	6
2.6	Additional WiSnap AAA Dongle Notes	7
3	Configuration	9
3.1	Entering Command Mode	9
3.2	Common Configurations	10
4	WiSnap Command Reference	12
4.1	Command Syntax	12
4.2	Command Organization	13
5	SET Commands	13
5.1	AD HOC Parameters	13
5.2	BROADCAST Parameters	14
5.3	COMM Parameters	14
5.4	DNS Parameters	15
5.5	FTP Parameters	15
5.6	IP Parameters	15
5.7	OPTIONAL Parameters	17
5.8	SYSTEM Parameters	18
5.9	TIME Server Parameters	20
5.10	UART Parameters	20
5.11	WLAN Parameters	21
6	GET Commands	24
7	STATUS Commands	25
8	ACTION Commands	26
9	FILE IO Commands	27
10	Advanced Features and Settings	27
10.1	System Timers and Auto Connect Timers	29
10.2	Wake on Sensor Input	30
10.3	Wake on UART	31
10.4	UART Receiver, RTS/CTS Hardware Flow Control	31
10.5	Setting GPIO direction, Alternate Functions and Disabling LEDs	32
10.6	Setting Debug Print levels	34
10.7	Scan Output Format	35
	Firmware Version 2.36 & 2.45	35
	Firmware Version 2.22 through 2.30	36
10.8	UART Heartbeat Messages	36
10.9	Using the Real Time Clock Function	37
10.10	Time Stamping Packets	38
11	Sending data using UDP	38
11.1	Overview	38
11.2	UDP Auto Pairing	39
11.3	UDP Retry	39
11.4	Using the UDP Broadcast Function	39
12	Joining Networks and Making Connections	40
12.1	Associate with a Network Access Point	40
12.2	Making Connections	41
12.3	Setting up Automatic Connections	42
12.4	Controlling Connections using PIO5 and PIO6	42
12.5	Using DNS Settings	42
12.6	Utilizing the Backup IP Address/Connect Function	43
13	Using HTML Client Feature	43
13.1	Built-in HTML Client Modes	43
13.2	Automatically Periodically Connect to Web Server	44

13.3	Automatically Connect to Web Server on UART Data	44
13.4	Posting Binary Data	45
13.5	Auto Posting Sensor Data	45
13.6	Examples Using the HTML Client	45
14	Firmware Upgrade over FTP	47
14.1	FTP Upload and Upgrade	47
15	Ad Hoc Networking Mode	48
15.1	Infrastructure and Ad Hoc Comparison	48
15.2	Configuring Ad Hoc Mode	48
15.3	Enable Ad Hoc Mode in Software	48
15.4	Scanning for Access Points in Ad Hoc Mode	49
15.5	Enable Ad Hoc Mode in Hardware	50
16	Access Point Networking Mode	50
16.1	Enabling AP Mode	50
16.2	Using Access Point Mode	51
17	Wi-Fi Protected Setup (WPS)	53
18	Analog Sensor Capability	55
	Automatic sampling of sensor pins	56
	Using the Built-In Sensor Power	56
19	Default Configuration Settings	57
19.1	Restoring Default Configuration Settings	59
20	Boot-up Timing Values	60
21	Supported 3 rd Party Access Points	60
22	Command List	61
23	Release Notes	64
23.1	Known Problems	64
23.2	Current Firmware Features and Fixes	64

1 Overview

The “WiSnap” radio module is a complete, standalone embedded wireless LAN access device. The device has an on-board TCP/IP stack and requires only 4 pins (POWER, TX, RX, GND) to design in. The RS-232 interface can transfer data to remote applications, such as an iPhone app, data logger, or PC control console. Once initial configuration is set, the radio can automatically access the Wi-Fi network and send/receive serial data over UART.

Features

- Fully Qualified and Wi-Fi Certified 2.4GHz IEEE 802.11b/g transceiver
- High throughput, up to 4Mbps sustained data rate with TCP/IP and WPA2
- Ultra-low power (4uA sleep, 40mA Rx, 210mA max Tx)
- Small, compact surface mount module
- On board ceramic chip antenna and U.FL connector for external antenna
- UART and SPI (future) data/control interfaces
- 10 general purpose digital I/O
- 8 analog inputs
- Real-time clock for wakeup and time stamping/data logging, auto-sleep and auto-wakeup modes
- Accepts 3.3V regulated or 2-3V battery with on board boost regulators
- Supports Ad-hoc and Infrastructure mode connections
- On board ECOS-OS, TCP/IP stacks
- Wi-Fi Alliance certified for WPA2-PSK
- FCC / CE/ ICS certified and RoHS compliant
- Host Data Rate Up to 2.7 Mbps for UART
- Memory 128 KB RAM, 2MB ROM, 2 KB battery-backed memory, 8 Mbit Flash
- Intelligent, built-in power management with programmable wakeup
- Can be powered from regulated 3.3-3.7V source or 2.0-3.0V batteries
- Configuration over UART or wireless interfaces using simple ASCII commands
- Over the air firmware upgrade (FTP), and data file upload
- Secure Wi-Fi authentication WEP-128, WPA-PSK (TKIP), WPA2-PSK (AES)
- Built in networking applications DHCP client, UDP, DNS client, ARP, ICMP ping, FTP, TELNET, HTTP
- 802.11 power save and roaming functions

One of the main applications for this device is the iPhone, since it requires buying additional authorization hardware to use Bluetooth SPP; the WiSnap in ad-hoc mode is a simple and cost effective way to connect to iPhone apps. The WiSnap Serial Adapter is more than a cable replacement solution. By allowing multiple TCP/IP sockets, applications can control and monitor hundreds of Wi-Fi Serial adapters remotely distributed across a building LAN or campus WAN.

2 Hardware Interface

Please see the specific data sheet on the SerialIO.com website for hardware specifications and layout information, located here: http://serialio.com/support/wifi/Serialio_WiSnap_GSX_Super_Module_Specs_2.0.pdf

2.1 Power

2.1.1 WiSnap M1 SuRFBoard

There are two options for powering the WiSnap module directly.

DC SUPPLY:

Apply 3.3 VDC power to VBATT (pin 20), and V3.3IN (pin 21).

Tie 3.3VREG-IN (pin 18) to GROUND.

Leave 3.3V-REG-OUT (Pin 17) floating/no connect.

BATTERY:

Apply battery = 2.0 to 3.3VDC to VBATT (pin 20). Leave V3.3IN pin 21 floating/no connect.

Tie pin 17 to pin 18. (This enables the on board battery boost 3.3V switcher).

There is a built in voltage brownout monitor which will shut down the chip when the voltage drops below 2.0 VDC.

➤ **Warning: Do NOT exceed these voltage ratings or damage to the module will occur!**

➤ **NOTES:**

- 1) The Sensor inputs SENS0-7 are extremely sensitive to over voltage. Under no conditions should these pins be driven above 1.2VDC. Placing any voltage above this will permanently damage the radio module and render it useless.
- 2) Placing 5VDC or any voltage above 3.3VDC into the VDD pins of the module will permanently damage the radio module.
- 3) Placing 3.3VDC into the PIO's while they are set as outputs will permanently damage the module. The failure mode is a short across GND and VCC.

2.1.2 WiSnap AAA Dongle

The WiSnap AAA Dongle is powered by two AAA batteries, an external AC to 5VDC power cable, or 5VDC (only) on pin 9 of the DB9 connector. Rechargeable NiMH batteries will be trickle charged when used with an external 5VDC (only) power source.

The power cable is center pin positive, outer cylinder GND. Input **MUST be 5 VDC** for proper battery charging. Higher voltages can permanently damage the charger and battery.

- **NOTE:** Although external power is possible, batteries MUST BE CONNECTED in order to complete the circuit. Without batteries, permanent damage to the unit may result.
- **WARNING: Do NOT use alkaline batteries while connecting any external power source. Doing so will cause permanent damage. If you desire to run off AC or external DC power, this can be accomplished by inserting NiMH re-chargeable batteries.**

Charging is a trickle charge; it typically takes 10 hours to charge batteries fully from low battery. The charge rate of the charger is low enough (< 100ma) such that the batteries can be charged indefinitely with no harm to them.

In configuration mode the **show bat** command will return the current battery voltage. Note that with rechargeable NiMH batteries, the voltage will remain relatively unchanged until they go dead.

2.2 Reset

- **NOTE:** The following only applies to the WiSnap M1 module.

Reset is active LOW and is optional/does not need to be connected. The reset pin is 3.3V tolerant and has an internal pull up of 100K to the VBATT.

2.3 UART

➤ **NOTE:** The following only applies to the WiSnap M1 module.

Connect a common ground when using the external TX, RX inputs. For a 3 wire DB-9 interface, connect TX, RX, and GND only.

Factory default is hardware flow control disabled; CTS and RTS are not required.

PIO's are not 5.0 VDC tolerant. If using a 5.0 VDC circuit, input, PIO and UART input pins require a resistor divider. A suggestion is to use a 10K resistor in series with 20k resistor to ground.

2.4 Status Indicators

2.4.1 WiSnap M1 SuRFBoard

PIO 4, 5 and 6 are active high and can be connected to external LEDs to provide network, connection and data status.

State	Red LED (PIO6)	Amber LED (PIO5)	Green LED (PIO4)
ON solid			Connected over TCP
Fast blink	Not Associated	Rx/Tx data transfer	No IP address or Config Mode
Slow blink			IP address OK
OFF	Associated		

2.4.2 WiSnap AAA Dongle

LEDs found on the WiSnap AAA are slightly different than on the M1.

State	Green LED	Yellow LED	Red LED	Blue LED
ON solid	Connected over TCP			Full charge
Fast blink	No IP address or Config Mode		Not Associated	Rx/Tx data transfer
Slow blink	IP address OK		Associated, No Internet	Low power
OFF			Associated, Internet OK	

The blue LED blinks when data is sent or received on the serial interface. This does not indicate that the data was sent over the Wi-Fi connection. If the blue LED is not flashing and your device is sending data to the serial port, you likely have a connection, incorrect baud rate, or HW flow control (RTS/CTS) problem.

The blue LED also indicates battery status and will blink slowly when the batteries are low except when charging. When charging the blue LED remains off. If the device is on while the batteries are charging the blue LED will come solid when the batteries are fully charged.

There is an additional red LED near the power connector that indicates external power is present at either the power plug of DB9 connector.

2.5 WiSnap M1 External Antenna

An external antenna with U.F.L connection can be mounted onto the WiSnap M1 module. This is most useful when the device will be embedded inside of another metal casing.

The FCC certified antenna has the following specifications:

Center Freq.	2.45 GHz
Bandwidth	120MHz
Wavelength	1/2-wave
VSWR	<1.9 typ. At center
Impedance	50 ohms
Gain	2.20dBi

Other antennas can be used, such as a higher gain antenna, but would not be FCC certified.

2.6 Additional WiSnap AAA Dongle Notes

2.6.1 Power Switch and Sleep


The red button on the top of the WiSnap AAA Dongle is a soft ON/OFF switch.

To turn ON the WiSnap AAA Dongle, press down the red button for 1 second, and then release it. You will see the green, yellow, red and blue LEDs flash in succession. After a moment the blue and yellow LEDs will go OFF, leaving the red and green LED flashing.

To turn OFF the WiSnap AAA Dongle, press down on the red button for 1 second, and then release it. The green, yellow, red and blue LEDs flash in succession several times. Then all the LEDs will turn off and the device will be in sleep mode.

By default, the WiSnap AAA Dongle automatically shuts itself off if not connected for more than 3 minutes = 180 seconds. The sleep timer duration is controlled by using the **set sys sleep** <seconds> command. Use the **get sys** command to display the current settings of the sleep timer.

2.6.2 Dipswitches



There are four small configuration switches on the top of the WiSnap AAA Dongle. You will need a paper clip or flat screwdriver to change them. Holding the device with the DB9 connector facing to the right, the switches are numbered one to four from bottom to top. The off position is towards the DB9 connector.

Switch 1 – Ad-hoc override and restoring factory defaults

There are two ways to enable ad-hoc mode from the WiSnap: hardware, and software. See **section 3.1** for more information about ad-hoc networking.

Note: Ad-hoc has been deprecated as of firmware version 4.41. If you require ad-hoc mode, contact Serialio prior to purchase to have an earlier firmware version installed on the WiSnap.

Software ad-hoc is recommended and is enabled by default.

If dipswitch 1 is ON when powering the WiSnap, the device will boot in hardware ad-hoc override mode. **This is only useful if the boot-up configuration is bad and you can't access the device otherwise.**

The SSID (network name) and other Wi-Fi settings are hardcoded and cannot be changed while in hardware ad-hoc mode. The SSID of the ad hoc network will be WiSnap-GSX-*NN* where *NN* is the last two digits of the devices MAC address.

To restore factory defaults, power on the device with this switch ON, and then toggle the switch five (5) times. If there is a config file named "user" on the WiSnap AAA Dongle file system, it is read in as the factory defaults instead of using the hardcoded defaults. If no "user" config file is present, the hardcoded factory defaults are used.


The "user" config file is created using the **save user** command, which saves the current configuration settings.

Even if there is a "user" config file arming and toggling this switch nine (9) times will override the "user" settings and restore the WiSnap module to the factory hardcoded defaults. This is a bypass mechanism in case a bad configuration is saved into the "user" file.

Switches 2, 3, and 4 are currently not used.

2.6.3 Serial Connector Specification

DB9 connector Pin Out



Pin	WiSnap AAA Male DB9	WiSnap AAA Female DB9
1	NC	NC
2	RXD	TXD
3	TXD	RXD
4	DTR (=PIO7)	DON'T USE
5	GND	GND
6	DSR (=PIO8)	5V DC (input)
7	RTS	CTS
8	CTS	RTS
9	5V DC Only	5V DC Only

- **NOTE:** The RS232 interface uses the SIPEX SP3232ECA chip with capacitor switch to generate the + and – signals and thus is not driving the full RS232 voltages. Devices stealing power from the RS232 pins may not have enough voltage.


2.6.4 Null-modem and Flow Control Jumpers

The WiSnap AAA Dongle serial interface can be configured to enable flow control and null modem signaling. The jumper block can be accessed by removing the battery cover from the WiSnap AAA Dongle.


- **WARNING:** Flow control signals are **NOT RS-232 signaling tolerant**. If these are enabled with the jumper, do not exceed 3.3 VDC or permanent damage can occur.

Male Units


Male DB9 (Default Config)
Jumper 1<>2, 3<>4




Male DB9 - Null Modem
Jumper 2<>4, 1<>3




Drive DTR on pin 4 of the male DB9
Jumper 7<>8



Drive DSR on pin 6 of the male DB9
Jumper 5<>6




Drive DCD on pin 1 of the male DB9
Jumper 9<>10




Female Units

Female DB9 (Default Config)
Jumper 2<>4, 1<>3




Female DB9 - Null Modem
Jumper 1<>2, 3<>4



Note: You can combine jumper configurations to achieve desired pinouts.

For example, if using the WiSnap AAA Male and wish to drive the DTR pin*, you would combine the jumpers in the first image (*Default Config*), and the third image (*Drive DTR*), so 3 jumpers total would be needed.

The image below shows a WiSnap AAA Male unit in the default configuration while also driving DTR**.



CAUTION: Do NOT apply *any* voltage ***externally*** to PIN 4 when Jumper "Drive DTR on pin 4 of the male DB9" is installed. Doing so will damage the module and void the warranty.

*DTR cannot be driven with female unit. See **section 2.6.3**.

Driving DTR requires additional I/O configuration. See **section 10.5.1 for more information.

3 Configuration

3.1 Entering Command Mode

Upon power up, the device will be in data mode. To enter command mode, send the three characters \$\$\$ and the device will respond with **CMD**.

While in command mode, the device will accept ASCII bytes as commands.

To exit command mode, send **exit**<cr>. The device will respond with "EXIT".

Parameters, such as the SSID, channel, IP address, Serial Port settings, and all other settings can be viewed and configured in command mode.

ASCII characters can be sent through a terminal emulator connected to the UART or via Telnet. When using the UART communications settings should match the settings used when RN-131g connects, for example: the default is 9600 baud rate, 8 bits, No Parity, 1 stop bit, and hardware flow control disabled.

Use TeraTerm, PuTTY, or SerialIO's JavaTerm as your terminal emulator. Please **DO NOT** use HyperTerminal as it is known to have issues with our products.

Type **\$\$\$** on in the terminal emulator. You should see "**CMD**" returned to you. This will verify that your cable and comm. settings are correct. Most valid commands will return an "**AOK**" response, and invalid ones will return an "**ERR**" description.

- **NOTE:** You can enter command mode locally over the UART interface at any time when not connected and also when connected if the appropriate settings are enabled.
- **NOTE:** When the WiSnap module is powered up, it tries to auto associate to the Access Point stored in the config settings. If for some reason the module cannot find the Access Point, it goes into auto association mode and gets busy scanning and trying to join a network. This may cause the UART to become unresponsive for a brief amount of time and you may lose the data sent to the module while the module is in this "not associated" state making it difficult to get into command mode and configure the module

Version 2.21 of the firmware fixes this issue. The auto-join feature is disabled when in command mode. This makes it easy to configure the module. Auto-join will re-enable when you exit out of command mode.

The auto join feature can be disabled by setting the **set wlan join 0**. This will prevent the WiSnap module to attempt to associate to a network that does not exist.

Another alternative is to boot the module in ad-hoc mode by using the PIO9 ad-hoc/factory reset jumper. If this is high on power up, the module will not associate to any network; it will use the temporary ad-hoc mode. When in ad-hoc mode, you can configure the network settings.

3.2 Common Configurations

Two common modes of operation for the WiSnap module are A) initiating a connection to a server and B) listening for a remote host connection. This section will go through the configuration for each setup. The setups are shown using infrastructure network. I.e. with an access point, however the same can be done with ad-hoc networking.

Initiating a connection from the WiSnap

Step 1: Set up the WLAN properties so the device will connect to the network automatically upon power up. In this example we want to connect to the wireless network *my_network*.

	Command	Result
1	set wlan join 1	Auto join upon power up
2	set wlan chan 0	Scan all channels
3	set wlan ssid <i>my_network</i>	Network name
4	set wlan phrase <i>my_secret_code</i>	Pass phrase

The **join 1** setting ensures that when the module wakes up, it tries to join the access point that matches the stored SSID, passkey and channel. Channel =0 (the default) will force auto-scanning. Setting the channel will reduce the time it takes the WiSnap to find and associate.

Step 2: Set up the IP address and port number of the remote server, so the WiSnap can connect when it wakes up.

	Command	Result
1	set ip host 10.20.20.75	Set the host IP address
2	set ip remote 3000	Set the remote port
3	set sys autoconn 2	Try to connect to the host every 2 seconds
4	save	Save configuration

➤ **NOTE:** If autoconn = 1, the WiSnap will only make one attempt to auto connect.

Step 3: Set the wake up and sleep conditions. By default the adapter will wake whenever there is data written to the serial interface. You can also configure the device to wake up on CTS, on a PIO or timer. See the command reference for details. We are going to set this up to wake on a timer then sleep after 2 minutes if there is no connection or if connected and no data has been transferred for 30 seconds.

	Command	Result
1	set sys sleep 120	Sleep after 2 minutes if no connection
2	set sys trigger 2	Wake on CTS
3	set conn idle 30	Disconnect after 30 seconds of no data
4	save	Save all the settings to the config file
5	reboot	Use the new settings

This setup can be tested using TCP server application that opens a socket on port 3000. Port Peeker is a free application that you can download off the web. It is available at <http://www.linklogger.com/portpeeker.htm>

Waiting for the remote host to connect to the serial adapter (listen mode)

In this example we are using a static IP so that the remote host knows where the WiSnap Serial adapter is on the network. Alternatively you can write your application software to listen for the broadcast UDP packet (automatically sent by WiSnap by default) to identify the WiSnap Serial adapter and get the IP address and TCP port number that the WiSnap is listening on.

Step 1: Set up the wlan properties so the device will connect to the network automatically upon power up. In this example we want to connect to the wireless network my_network.

	Command	Result
1	set wlan join 1	Auto join upon power up
2	set wlan chan 1	Only look on channel 1
3	set wlan ssid my_network	Network name
4	set wlan phrase my_secret_code	Pass phrase

Step 2: Configure the WiSnap static IP address so the remote application can connect, turn off DHCP and set the IP address and netmask.

	Command	Result
1	set ip address 10.20.20.63	Set the IP address
2	set ip localport 5030	Set the local port to listen on
3	set ip netmask 255.255.255.0	Set the IP netmask
4	set ip gateway 10.20.20.1	Set the network gateway
5	set ip dhcp 0	Turn of DHCP

Step 3: Set the wake up and sleep conditions. In this mode the sleep and wake timers are used to conserve battery. Since we don't know when the remote host will connect, the module should occasionally wake up and listen for the remote host. The trade off with these timers is that the longer you sleep, the better your battery life will be but the longer it will take the remote host to connect.

- **WARNING: Do not set the sleep timer below 5 seconds or it will be impossible to get into command mode to reprogram this mode without it going back to sleep!**

	Command	Result
1	set sys wake 20	Wake after 20 seconds
2	set sys sleep 10	Go to sleep after 10 seconds
3	save	Save configuration
4	reboot	Restart using the new configuration

At this point you could test this configuration using telnet on a computer sharing the same network to connect to the WiSnap module.

Enabling Access Point Mode (Requires firmware to 2.42 and higher)

Devices using firmware versions 2.42 and higher are able to put the device into Access Point mode. Access point mode allows for an alternative for connecting android devices. The device can be put into access point mode by issuing the following commands:

	Command	Result
1	set wlan ssid WiSnap	Set the Access Point SSID
2	set wlan join 7	Create an access point on power up
3	set ip dhcp 4	Turn on the DHCP server
4	set wlan chan 1	Only broadcast on channel 1
5	set ip address 1.2.3.4	Set the IP address for the WiSnap device
6	set ip net 255.255.255.0	Set the subnet mask
7	set ip gateway 1.2.3.4	Set the Access Point gateway
8	save	Save configuration
9	reboot	Restart using the new configuration

When the device reboots, it should be in access point mode.

4 WiSnap Command Reference

4.1 Command Syntax

Commands begin with a keyword, and have optional additional parameters, generally space delimited. Commands and options **are** case sensitive. Hex input data can be upper or lower case. String text data, such as SSID is also case sensitive.

The first command is fully decoded and must be complete. Other command parameters can be shorted by using only the first character.

For example,

set uart baud 115200 is valid

set uart b 115200 is also valid

set u b 115200 is also valid

however,

s uart baud 115200 is NOT valid.

Numbers can be entered as either decimal, (like 115200 above) or hex. To enter hex, use “0x” before the value: **0x<value>**. For example, the hex value FF would be entered as 0xFF.

4.2 Command Organization

Commands fall into 5 general categories:

- **SET COMMANDS** - Changes settings immediately and permanently (save command issued).
- **GET COMMANDS** - Retrieve the permanently stored information for display to user.
- **STATUS COMMANDS** - See what is going on with the interface, IP status, etc.
- **ACTION COMMANDS** - Perform action such as scan, connect, disconnect, etc.
- **FILE IO COMMANDS** - Upgrade, load and save configuration, delete files, etc.

➤ **NOTE:** You must save any changes made or the module will load the previous settings upon reboot or power up.

When the system boots, all configuration data is loaded into RAM variables from the file called “config”. The **set** commands actually only modify the RAM copy of variables in the system. In general, the IP, WLAN and UART settings need a **save** and **reboot** to take effect, since they operate at boot up time. For example: At power up, you will only associate, set the channel and get your IP address once.

Most of the other commands take effect immediately like the COMM settings and timers. This allows temporary change of parameters “on the fly” to test features, minimize power usage and save on flash re-write cycles.

Once all configuration is complete, the user must save the settings using the **save** command to store the configuration data, otherwise it will not take effect upon reboot or reset. Multiple configurations can be stored by using the **save <filename>** command, and these configurations can be loaded using the **load <filename>** command.

5 SET Commands

These commands begin with **set**. There are 11 major categories.

- **AD-HOC** - controls the ad-hoc parameters
- **BROADCAST** - controls the broadcast hello/heartbeat UDP message
- **COMM** - communication and data transfer, timers, matching characters
- **DNS** - DNS host and domain
- **FTP** - FTP host address and login information
- **IP** - IP settings
- **OPTION** - optional and not frequently used parameters
- **SYS** - system settings such as sleep and wake timers
- **TIME** - timer server settings
- **UART** - serial port settings such as baud rate and parity
- **WLAN** - wireless interface settings, such as SSID, channel, and security options

5.1 AD-HOC Parameters

set ad-hoc beacon *<ms>* - sets the ad-hoc beacon interval in milliseconds where *<ms>* is a decimal number from 0 to 65,436. Default is 100.

set ad-hoc probe *<num>* - sets the ad-hoc probe retry count. Default is 5. This is the number of consecutive probe responses that can be lost before declaring “AD- HOC is lost” and disabling the network interface.

5.2 BROADCAST Parameters

set broadcast address *<addr>* - sets the address to which the UDP hello/heartbeat message is sent. The default address is 255.255.255.255.

set broadcast interval *<value>* - sets the interval at which the hello/heartbeat UDP message is sent. Interval is specified in seconds. The value is a mask that is ANDed (compared) to a free running seconds counter. For example:

- If the interval is 0x1, the module sends one packet every 2 seconds.
- If the interval is 0x2. The module sends two packets every 4 seconds.
- If the interval is 0x3, the module sends one packet every 4 seconds.
- If the interval is 0x6, the module sends two packets every 8 seconds.
- If the interval is 0x7, the module sends one packet every 8 seconds.

The minimum interval value is 1 (every 2 seconds) and max value is 0xff (every 256 seconds). Setting the interval value to zero disables sending UDP broadcast messages. The default interval is 7.

set broadcast port *<port>* - sets the port number to which the UDP hello/heartbeat message is sent. The default port is 55555.

5.3 COMM Parameters

set comm \$ *<char>* - sets character used to enter command mode. Typically used when “\$\$\$” is a possible data string. Default is “\$”. Care should be taken when setting this to note the new character as once this setting is saved every subsequent reboot will ignore “\$\$\$” and look for “*<char><char><char>*”.

set comm close *<string>* - sets the ASCII string that is sent to the local UART when the TCP port is closed. If no string is desired, use 0 as the *<string>* parameter. Max string length is 32 characters. Default is *CLOS*

set comm open *<string>* - sets the string that is sent to the local UART when the TCP port is opened. If no string is desired, use 0 as the *<string>* parameter. Max string length is 32 characters. Default is *OPEN*

set comm remote *<string>* - sets the string that is sent to the remote TCP client when the TCP port is opened. If no string is desired, use 0 as the *<string>* parameter. Max string length is 32 characters. Default is *HELLO*

set comm idle *<secs>* - sets the Idle Timer Value. This is the number of seconds with no transmit or receive data before the connection is closed automatically. Default is 0, never disconnect on idle.

set comm match *<value>* | *<hex>* - sets the match character, where *<value>* is a decimal number from 0 to 127 or a hex number from 0 to 7F. When this configuration option is set, the module sends an IP packet each time the match character appears in the data. You enter *<value>* either as the decimal (e.g., 13) or hex (e.g., 0xd) equivalent of the of the ASCII character. Setting the match character to 0 disables matching.

Flush timer is one of three ways to control TCP/IP packet forwarding. The others are match character and size. For more information see section 10.4.

set comm size *<value>* - sets the flush size. An IP packet will be sent each time *<value>* bytes are received. Default is 64 bytes. You should set this value to the largest possible setting to maximize TCP/IP performance. Maximum value = 1420 (at 9600) bytes.

- **NOTE:** This value is set automatically when the baud rate is set, in an attempt to optimize the link. It is assumed that higher baud rates equate to more data and hence the flush size is increased.

Flush size is one of three ways to control TCP/IP packet forwarding. The others are match character and timer. For more information see section 10.4.

set comm time *<num>* - sets the flush timer. An IP packet will be sent if no additional bytes are received for *<num>* milliseconds. *<num>* is one milliseconds intervals. 1 is the minimum value. Default is 10 (10 milliseconds). Setting this value to 0 will disable forwarding based on the flush timer.

Flush timer is one of three ways to control TCP/IP packet forwarding. The others are match character and size. For more information see section 10.4.

5.4 DNS Parameters

set dns address *<addr>* - sets the IP address of the DNS sever, where *<address>* is an IP address in the form *<octet>.<octet>.<octet>.<octet>* with *<octet>* being a number between 0 and 255. This address is automatically set when using DHCP; you must set the DNS IP address for static IP or automatic IP modes.

set dns name *<string>* - sets the name of the host for TCP/IP connections to *<string>*, where *<string>* is up to 32 characters (32 bytes).

set dns backup *<string>* - sets the name of the backup host for TCP/IP connections to *<string>*, where *<string>* is up to 32 characters (32 bytes). The FTP client uses the backup string to download the firmware via the **ftp update** command. Default: rn.microchip.com

5.5 FTP Parameters

set ftp dir *<string>* - sets the starting directory on the FTP server, where *<string>* is up to 32 characters. To read/write to subfolders, use the \ character. To indicate the root directory, use a period.

set ftp filename *<file>* - sets the name of the file transferred when issuing the **ftp u** or **ftp g** commands, where *<filename>* is the firmware image. If you specify any file other than the firmware image, the WiSnap module downloads the file and issues the **UPDATE FAIL=3** error.

set ftp addr *<addr>* - sets the ftp server IP address. Default 0.0.0.0.

set ftp remote *<port>* - sets the ftp server remote port number (default is 21).

set ftp user *<name>* - sets the ftp user name for accessing the FTP server.

set ftp pass *<pass>* - sets the ftp password for accessing the FTP server.

set ftp time *<value>* - sets the FTP timeout value, where *<value>* is a decimal number that is five times the number of seconds required. The module uses this timer to close the FTP connection automatically after the specified time.

5.6 IP Parameters

set ip address <addr> - sets the IP address of the WiSnap module, where <address> is an IP address in the form <octet>.<octet>.<octet>.<octet> with <octet> being a number between 0 and 255. If DHCP is turned on, the IP address is assigned and overwritten during association with the access point.

- Example: **set ip a** 10.20.20.1

set ip backup <addr> - sets a secondary host IP address. If the primary host IP is not reachable the module will try the secondary IP address if set.

set ip dhcp <value> - enable/disable DHCP mode. If enabled, the IP address, gateway, netmask, and DNS server are requested and set upon association with access point. Any current IP values are overwritten.

DHCP Cache mode can reduce the time it takes the module to wake from deep sleep thus saving power. In cache mode, the lease time is checked and if not expired, the module uses the previous IP settings. If the lease has expired the module will attempt to associated and use DHCP to get the IP settings. DHCP cached IP address does not survive a power cycle or reset.

Mode	Protocol
0	DHCP OFF, use stored static IP address
1	DHCP ON, get IP address and gateway from AP
2	Auto-IP, generally used with Ad hoc networks
3	DHCP cache mode, uses previous IP address if lease is not expired (leave survives reboot)
4	Enables DHCP server in soft AP mode

set ip flags <value> - sets TCP/IP advanced functions. Value is a bit mapped flag register. Default = 0x7.

Bit	Protocol
0	TCP connection status - see note below
1	Bypass Nagle algorithm and use TCP_NODELAY
2	TCP retry enabled (42 total)
3	UDP retry (attempts retry if no ACK from UDP)
4	DNS host address caching enabled
5	ARP table caching enabled
6	UDP auto pairing enabled
7	Add 8 byte timestamp to UDP or TCP packets

- **NOTE:** When the link to an associated to an access point is lost while a TCP connection is active, the TCP connection can be left in a hung/inconsistent state. In some cases, the TCP connection will not recover. In version 2.20 and later, if the link to the access point is regained within 60 seconds, the TCP connection will survive.
- With version 2.20 we have changed the operation of bit0 in the “ip flags” register. Previously this bit specified the TCP copy function, but controls the TCP socket function while associated on a network.
 - If bit 0 is set (default) TCP connections are kept open when the connection to the access point is lost.
 - If bit 0 is cleared (by setting “set ip flags 0x6” for example) then when the connection to the access point is lost and TCP is connected, the connection will be closed.

set ip gateway <addr> - sets the gateway IP address, If DHCP is turned on, the gateway IP address is assign and overwritten during association with the access point.

set ip host <addr> - sets the remote host IP address. This command is used for making connections from the WiSnap module to a TCP/IP server at the IP address <addr>.

set ip localport <num> - sets the local port number to listen for incoming connections, where <num> is an integer number representing the port.

set ip netmask <value> - sets the network mask. If DHCP is turned on, the net mask is assign and overwritten during association with the access point.

set ip protocol <value> - sets the IP protocol. Value is a bit mapped setting. To connect to the WiSnap module over TCP/IP such as Telnet the device must have the use the TCP Server protocol / bit 2 set. To accept both TCP and UDP use value = 3 (bit 1 and bit 2 set).

Bit Position	Protocol
0	UDP
1	TCP Server & Client (Default)
2	Secure (only receive packets when IP address matches the store host IP)
3	TCP Client only
4	HTTP client mode

set ip remote <value> - sets the remote host port number for outgoing connections.

set ip tcp-mode <mask> - controls the TCP connect timers, DNS preferences, and remote configuration options. <mask> is a hex number referring to a bit-mapped register as shown below.

Bit Position	Protocol
0	Shorten the TCP connect timer (use with bit 1)
1	Shorten the TCP connect timer (use with bit 0)
2	Forces the module to use DNS first to resolve the IP address, even if the host IP is set
3	Reserved
4	Disables remote configuration security purposes

▪ Example:

- **set ip tcp-mode 0x4** – Forces the module to use DNS
- **set ip tcp-mode 0x10** – Disables remote configuration

5.7 OPTIONAL Parameters

set opt jointmr <msecs> - join timer is the time in milliseconds (default=1000) the join function will wait for an access point to complete the association process. This timer is also the timeout for the WPA handshaking process.

set opt sensor <mask> - deprecated in firmware versions 2.23 and later. Use **set q sensor**. Bitmask value that determines which sensor pins to sample when sending data using the UDP broadcast packet and the HTTP auto sample function.

set q sensor <mask> - specifies which sensor pins to sample when sending data using the UDP broadcast packet or the HTTP auto sample function, where <mask> is a bit-mapped register.

- Example: **set q sensor 0xff**.

➤ **NOTE:** In versions of firmware prior to 2.23, this command is named **set option sensor**

set opt replace <char> - replacement character for spaces. The replacement character is used when entering SSID and pass phrases that include space. This is used by the WiSnap command parser only. Each occurrence of the replacement character is changed into a space. The default is "\$" (0x24).

set opt format <mask> - settings for HTTP client/web server value is a bitmapped register. See Section 13, web server modes.

Bit	Function
0	Automatically send HTML data header based on broadcast interval
1	Send users BINARY data (converted to ASCII hex)
2	Sample the TPIO and AtoD pins format to ASCII hex
3	Appends &id = <the value of the deviceid string set with "set opt device <string>">
4	Appends &rtc = <real time clock value in message as 32 bit HEX value in format aabbccddeeff>

set opt deviceid <string> - Configurable Device ID - can be used for storing serial numbers, product name or other device information. This information is sent as part of the broadcast hello packet that is sent as a UDP. The current value can be shown with the **get option** or **show deviceid** commands. Max string size is 32 bytes. The default is "WiSnap<DEVICEID>M1".

set opt password <string> - TCP connection password. Provides minimal authentication by requiring any remote device that connects to send and match a challenge <string>. When set, all newly opened connections must first send the exact characters that match the stored password otherwise the WiSnap module will close the connection. When the password is set, the WiSnap module sends the string "PASS?" to the remote host. All characters in the string must be sent in one TCP packet. Max string size is 32 bytes. To disable the password feature use string=0 which is the default.

5.8 SYSTEM Parameters

set sys autoconn <secs> - TCP mode: sets the auto connect timer. This command causes the module periodically connect to the host. The timer <secs> determines how often to connect to the stored remote host. If set to 1, the module will only make one attempt to auto connect upon power up. If set to 2 or greater, auto connect will re-open the connection after the connection is closed. Default=0 disables.

set sys autosleep <num> - sets the auto-sleep timer. 0 disables. If the protocol is set to UDP ONLY, this timer is used as a quick sleep function. Device will sleep <num> ms after transmission of the first UDP packet.

set sys iofunc <value> - sets the IO port alternate functions. Bit-mapped value. For more details see section 10.5

set sys mask <mask> - sets the IO port direction mask. Bit-mapped value. For more information see section 10.5

set sys printlvl <value> - sets the debug print messages printed by the WiSnap module on the UART, where <value> is one of the values shown on the table below. Default is 1.

Value	Description
0	Quiet mode. Messages are not printed when the module wakes up or powers up.
1	Print all status messages.
2	Print only critical network access point connection level status, e.g., Associated! or Disconnect from <SSID>.
4	Print the DHCP and IP address status information. After you have verified the module's configuration, you can turn off this option so that the messages do not interfere with the data.
0x4000	Change the scan format output to an MCU friendly format.
0x10	Enables the UART heartbeat message.

set sys output <value> <mask> - sets output PIO pins to HIGH or LOW. Bit-mapped value. Optional mask only sets a subset of pins.

- Example: To toggle GPIO8, use the following commands:
 - **set sys mask 0x21f0** - Set GPIO8 as output

- **set sys output 0x0100 0x0100** - Drives GPIO8 high
- **set sys output 0x0000 0x0100** - Drives GPIO8 low

set sys sleep <secs> - sets the sleep timer, where <value> is a decimal number. The sleep timer is the time (in seconds) after which the module goes to sleep. This timer is disabled during an open TCP connection. When the TCP connection is closed, the module counts down and puts the module to sleep after <value> seconds. Setting the value to 0 disables the sleep timer, and the module will not go to sleep based on this counter. 0 disables.

- **NOTE:** If not using Sensor pins to wake the module, be sure to set the wake timer before issuing the sleep timer or the module will not wake up.

See section 10.1 for more details on using system timers

set sys trigger <flag>| <mask> - sets the sensor input(s) to wake on (0-3). With this parameter setting, the module wakes from sleep state using the sensor input 0, 1, 2, and 3, where <flag> is a decimal number referring to a bit-mapped register as shown in the table below and <mask> is a hex number. You use either <flag> or <mask> with this parameter setting. This command sets the sensor input(s) to wake on (0 to 3). Setting <flag> to 0 disables wake on sensor inputs. Bit-mapped value.

Bit Position	Description
0	Trigger sensor input 0
1	Trigger sensor input 1
2	Trigger sensor input 2
3	Trigger sensor input 3
4	Enable WPS function
5	Enable sleep on GPIO8

The following table describes how you can wake the module using sensor input.

Wake on Sensor Input	Value	Command
0	1	set sys trigger 1
1	2	set sys trigger 2
2	4	set sys trigger 4
3	8	set sys trigger 8

- **NOTE:** Setting the system trigger value to **0x10** enables WPS functionality. WPS is disabled by default.

Setting the trigger value to 0x20 (i.e., using <mask>) puts the module to sleep when GPIO8 is pulled high. To enable this feature, use the **set sys trigger 0x20** command. This command makes GPIO8 an interrupt pin and puts the module to sleep as soon as it is pulled high, regardless of the module's state; the module goes to sleep even if it is associating with a network or has an open, active TCP connection.

This command is useful for when the module is failing to associate with network because it is out of range (or for any other reason), or if the module must be put to sleep quickly.

- **NOTE:** GPIO8 must be low on power up and stay low until you want to put the module to sleep.

set sys wake <secs> - sets the auto wake timer. 0 disables. See section 10.1 for more details on using system timers.

set q power <value> - register automatically turns on the sensor power, where <value> is shown in the table below. This parameter sets an 8-bit register with two 4-bit nibbles. If the top nibble is set, power is applied upon power up and removed upon power down or sleep. If the bottom nibble is set, power is applied when a sampling event occurs such as:

- UDP broadcast
- Automatic web posting of sensor data
- Power is removed immediately after sampling is complete

Value	Sensor pin voltage
0	Turn off the sensor power
1	Ground the sensor pin
2	1.2-V internal regulated reference
3	VBATT input pin
4	3.3-V output of on-board regulator

- Example:
 - **set q power 0x20** - Sets power to 1.2 V automatically upon power up
 - **set q power 0x02** - Sets power to 1.2 V when a sampling event occurs
 - **set q power 0x40** - Sets power to 3.3 V automatically upon power up
 - **set q power 0x04** - Sets power to 3.3 V when a sampling event occurs

5.9 TIME Server Parameters

set time address *<addr>* - sets the time server address. (sNTP servers)

set time port *<num>* - sets the time server port number. Defaults to 123 which is almost always the sNTP server port.

set time enable *<value>* - enable or disable fetching time from the specified sNTP time server. Default=0= disabled. A value of 1 gets time only once on power up. Any value > 1 gets time continuously every *<value>* minutes.

set time raw *<value>* - setting parameter allows you to set the RTC raw value from the console, where *<value>* is a decimal number in seconds. The RTC ticks at 32,768 Hz.

5.10 UART Parameters

set uart baud *<rate>* - sets the UART baud rate. Valid settings are {2400, 4800, 9600, 19200, 38400, 57600, 115200, 230400}.

- Example: **set u b 9600** sets the baud rate to 9600 baud.

➤ **NOTE:** the RS-232 interface on the WiSnap does not work below 2400 or above 230400 baud.

set uart instant *<rate>* - this immediately changes the baud rate, where *<value>* is 2400, 4800, 9600, 19200, 38400, 57600, 115200, 230400, 460800, or 921600. This is useful when testing baud rate settings, or switching baud rate “on the fly” remotely while connected over TCP. This setting does not affect configuration. Returns the AOK response, but will not exit command mode.

- **NOTE:** In firmware version 2.22 and lower, the module does NOT return an **AOK** over telnet before exiting command mode.

If used in local mode, the baud rate changes and the module sends **AOK** using the new baud rate. If the host switches to the new baud rate immediately, the host may see the **AOK** string at the new baud rate. Depending on the baud rate, it takes at least ten times the bit rate for the module to issue the first character.

set uart raw *<value>* - sets a RAW UART value, where *<value>* is a decimal number representing the baud rate. Used to set non-standard rates. The lowest possible baud rate is 2400.

Using non-standard raw baud rates with hardware flow control can be more useful at speeds as the microcontroller interfaced to the module may be able to better match the UART speed and get better results. The table below shows the supported raw baud rates:

Raw Baud Rate	Comment
458333	This is 460800
500000	Raw baud rate
550000	Raw baud rate
611111	Raw baud rate
687599	Raw baud rate
785714	Raw baud rate
916667	This is 921600
1100000	Raw baud rate

- Example: **set u r 7200** sets the baud rate to 7200 baud.

set uart flow *<value>* - sets the flow control mode and parity, where *<value>* is a hex number. The setting is in the upper nibble of the hardware flow control setting. The default is flow control disabled with parity set to none/no parity. Default=0=off, 1=hardware RTS/CTS.

- **NOTE:** once flow control is enabled, it is important to properly drive the CTS pin (active LOW enabled). If CTS is HIGH, data will NOT be sent out the UART, and further configuration in command mode will be problematic as no response will be received.

- Example:
 - **set uart flow 0x21** – Even parity with flow control
 - **set uart flow 0x20** – Even parity without flow control
 - **set uart flow 0x31** – Odd parity with flow control
 - **set uart flow 0x30** – Odd parity without flow control

set uart mode *<mask>* - sets the UART mode register, where *<mask>* is a hex number masking a bit-mapped value as shown below.

Bit Position	Function
0	NOECHO – disables echo of RX data while in command mode
1	DATA TRIGGER makes connection on RX data
2	Reserved
3	Enable Sleep on RX BREAK signal
4	UART RX data buffer. See note below
5	The version string <i><x.xx></i> \r\n is replaced with the replace character in the command prompt (\$ by default)

- **NOTE:** With firmware version 2.27 and higher, bit 4's functionality has changed. When a TCP connection is closed, if there is RX data in the UART receiver, it is flushed by default.

When a TCP connection is closed, currently if there is RX data in the UART receiver, it is held until:

- 1) more chars come in, in which case it will get flushed, or
- 2) no chars come in and a new connection is made, then the chars will get forwarded.

- Example: **set uart mode 0x10** - Enable the UART data buffer

set uart tx *<0, 1>* - disables or enables the UART's TX pin (GPIO10), where *<value>* is 1 or 0. Disabling the pin (*<value>* = 0) sets GPIO10 as an input with a weak pull down.

- **NOTE:** Firmware version 2.36/2.45 and higher supports parity with the **set uart flow** command.

5.11 WLAN Parameters

set wlan auth <value> - sets the authentication mode. Not needed unless using auto join mode 2. i.e. **set wlan join 2**

- **NOTE:** During association the WiSnap module interrogates the Access Point and automatically selects the authentication mode.

The current release of WiSnap firmware supports these security modes:

- WEP-128 (open mode only, NOT shared mode)
- WPA2-PSK (AES only)
- WPA1-PSK (TKIP only)
- WPA-PSK mixed mode (some APs, not all are supported)

Value	Authentication Mode
0	Open (Default)
1	WEP-128
2	WPA1
3	Mixed WPA1 & WPA2-PSK
4	WPS2-PSK
5	Not Used
6	Ad hoc, Join any Ad hoc network
8	WPE-64

- **NOTE:** Currently, WPA2-Enterprise security networks requiring a username are not currently supported.

set wlan channel <value> <flag> - sets the wlan channel, where <value> is a decimal number from 1 to 13 representing the valid range for a fixed channel. If 0 is set, then a scan is performed, using the SSID, for all the channels set in the channel mask. The <flag> is the optional character i (meaning immediate). The i flag allows you to create a temporary AP mode setup without having to reboot or save the settings. See example 2 below:

- Example 1:
 - **set wlan channel 2** – sets the WLAN channel to 2
- Example 2:
 - **set wlan channel 1 i**
 - **set wlan join 7**
 - **set ip address 1.2.3.4**
 - **set ip gateway 1.2.3.4**
 - **set ip netmask 255.255.255.0**
 - **set ip dhcp 4** – Use DHCP server
 - **join <SSID>** - Module goes into AP mode

set wlan ext_antenna <0, 1> - determines which antenna is active, use 0 for chip antenna, 1 for U.F.L connector. Default = 0. Only one antenna is active at a time and the module must be power cycled after switching the antenna.

set wlan join <value> - sets the policy for automatically joining/associating with network access points. This policy is used when the module powers up, including wake up from the sleep timer.

Value	Policy
0	Manual, do not try to join automatically.
1	Try to join the access point that matches the stored SSID, passkey, and channel. Channel can be set to 0 for scanning (Default).
2	Join ANY access point with security matching the stored

	authentication mode. This ignores the stored SSID and searches for the access point with the strongest signal. The channels searched can be limited by setting the channel mask.
3	Reserved – Not used.
4	Create an Ad hoc network, using stored SSID, IP address, and netmask. Channel MUST be set. DHCP should be 0 (static IP) or set to Auto-IP with this policy (unless another Ad hoc device can act as DHCP server). This policy is often used instead of the hardware jumper to create a custom Ad hoc network.
7	Create a soft AP network using stored SSID, IP address, netmask, channel, etc. This mode applies only to firmware version supporting soft AP mode and not ad hoc mode.

set wlan hide <0,1> - hides the WEP key and WPA passphrase. When set, displaying the wlan settings shows ***** for these fields. To unhide the passphrase or passkey, re-enter the key or passphrase using the **set wlan key** or **set wlan passphrase** command. Default = 0, don't hide.

set wlan key <value> - sets the 128 bit WEP key. If you are using WPA or WPA2 you should enter a pass phrase with the **set wlan passphrase** command. Key must be EXACTLY 13 bytes (26 ASCII chars). Data is expected in HEX format, leading "0x" should NOT be used here.

- Example : **set w k 112233445566778899AABBCCDD**

Hex digits > 9 can be either upper or lower case.

The WiSnap only supports "open" key mode, 128 bit keys for WEP. WEP-128, shared mode is not supported as it is known to be easily compromised and has been deprecated from the Wi-Fi standards.

set wlan linkmon <value> - sets the link monitor timeout threshold. If set to 1 or more, WiSnap will scan once per second for the AP it is associated with. The value is the threshold of failed scans before the WiSnap declares "AP is Lost", de-authenticates. The WiSnap will retry the association based on the join policy variable. A value of 5 is recommended, as some APs will not always respond to probes. Default is 0 (disabled). Without enabling this feature, there is no way to detect if an AP is no longer present until it becomes available again (if ever).

set wlan mask <value> - sets the wlan channel mask used for scanning channels with the auto-join policy 1 or 2, used when the channel is set to 0. Value is a bit- map where bit 0 = channel 1. Input for this command can be entered in decimal or hex if prefixed with 0x. Default value is 0x1FFF (all channels).

set wlan num <value> - sets the default WEP key to use. 1-4 is the valid range.

- Example: "set w n 2" sets the default key to 2.

set wlan phrase <string> - sets the passphrase for WPA and WPA2 security modes. 1-64 chars. The passphrase can be alpha and numeric, and is used along with the SSID to generate a unique 32 byte Pre-shared key (PSK), which is then hashed into a 256 bit number. Changing either the SSID or this value re-calculates and stores the PSK.

If exactly 64 chars are entered, it is assumed that this entry is already an ASCII HEX representation of the 32 byte PSK and the value is simply stored.

For passphrases that contain spaces use the replacement character \$ instead of spaces. For example "my pass word" would be entered "my\$pass\$word". The replacement character can be changed using the optional command **set opt replace <char>**.

- Example: **set w p password** - sets the phrase to 'password'.

set wlan rate <value> - sets the wireless data rate. Lowering the rate increases the effective range of the WiSnap module. The value entered is mapped according to the following table:

Value	Wireless Data Rate
0	1 Mbit/sec
1	2 Mbit/sec
2	5.5 Mbit/sec
3	11 Mbit/sec
4 – 7	Invalid
8	6 Mbit/sec
9	9 Mbit/sec
10	12 Mbit/sec
11	18 Mbit/sec
12	24 Mbit/sec (default)
13	36 Mbit/sec
14	48 Mbit/sec
15	54 Mbit/sec

set wlan ssid <string> - sets the WLAN SSID to associate with. 1-32 chars.

- **NOTE:** If the passphrase or SSID contain SPACE (' ') characters, these can be entered using substitution via the "\$" character.

For example, if the SSID of the AP is "yellow brick road" You would enter "yellow\$brick\$road"

Using the **get w** command will properly display the value: SSID=yellow brick road.

set wlan window <value> - sets the IP maximum buffer window size. Default is 1460 bytes.

set wlan tx <value> - sets the Wi-Fi transmit power, where <value> is a decimal number from 1 to 12 that corresponds to 1 to 12 dBm. The default, 0, corresponds to 12 dB, which is the maximum TX power. Setting the value to 0 or 12 sets the TX power to 12dBm.

- **NOTE:** This command applies only to the RN-171 module; it is not applicable to the RN-131. The transmit power on the RN-131 is fixed to 18 dBm. If you send this parameter to the RN-131, it issues an error message **ERR: Bad Args**.

6 GET Commands

These commands begin with **get**. They display the current values.

get ad-hoc - displays all ad-hoc settings.

get broadcast - displays the broadcast UPD address, port, and interval

get com - displays comm settings.

get dns - displays DNS settings.

get everything - displays all configuration settings, useful for debug.

get ftp - displays FTP settings.

get ip <a> - displays IP address and port number settings. If the "a" parameter is added on, only the current IP address value will be shown.

get mac - displays the device MAC address.

get optional - displays the optional settings like device ID.

get q - displays the sensor settings (sensor mask and sensor power settings).

get sys - displays system settings, sleep, wake timers, etc.

get time - displays the time server UDP address and port number.

get wlan - displays the SSID, channel, and other WLAN settings.

get UART - displays the UART settings.

ver - returns the software release version.

7 STATUS Commands

These commands begin with **show**, and they return the current values of variables in the system. In some cases, for example IP addresses, the current values are received from the network, and may not match the stored values. Except where noted, the **show** commands do not have any parameters.

show bat - displays current battery voltage, (only valid for SerialIO.com battery powered products like the WiSnapAAA)

show connection - displays connection status in this HEX format: 8XYZ

Bit Location	Function	Value
0-3	TCP status	0 = Idle 1 = Connected 3 = NOIP 4 = Connecting
4	Associate	1 = OK
5	Authenticate	1 = OK
6	DNS server	1 = contacted
7	DNS found	1 = resolved
9-12	channel	1-13
13-16	fixed	8

show io - displays IO pin levels status in this HEX format: 8<ABC>. For example: **show i** returns 8103 - indicates pins 0, 1 and 9 high level.

show net <char> - displays the current network status, association, authentication, etc., where <char> is the optional parameter **n**. Using the **n** parameter displays only the MAC address of the access point with which the module is currently associated.

show rssi - displays current last received signal strength.

show stats - displays current statistics, packet rx/tx counters, etc.

show time - displays number of seconds since last powerup or reboot.

show q <0-7> - displays the value of the analog interface pin, where <value> is 0 to 7. The A/D reading is 14 bits with a range of 0 to 400 mV (therefore, the resolution is 24 uV). The output is in uV (1,000 millivolts). The module returns a value in the format

8xxxxx, where xxxxx is the voltage in microvolts sampled on the channel you requested.

- **NOTE:** If a web post or UDP broadcast samples the data, the data is shifted as described in the “UDP Broadcast” section.

show q 0x1 <mask> - displays multiple analog interface values at once. The channels displayed is controlled by a bit mask which is preceded by a 0x1xx where xx mask is the bit mask of the channels. For example, to read channels 0, 1, and 7, send: **show q 0x183** which returns 8<chan0>, 8<chan1>, 8<chan7>, \r\n

8 ACTION Commands

The action commands allow you to enter and exit command mode, join networks, etc. Except where noted, these commands do not have any parameters.

\$\$\$ - enter command mode. Characters are PASSED until this exact sequence is seen. If any bytes are seen before these chars, or after these chars, in a 250ms window, command mode will not be entered and these bytes will be passed on to other side.

close - disconnect a TCP connection.

exit - exit command mode. “EXIT” will be displayed.

factory RESET - loads factory defaults into the RAM configuration. **Note that the RESET must be capitalized.** This command also writes the settings out to the standard config file. After this command the module then needs to be rebooted for settings to take effect.

join <ssid> - joins the network <ssid>. If network is security enabled you must set the pass phrase with the **set wlan phrase** command prior to issuing the **join** command.

- **NOTE:** The <ssid> must not contain spaces. If the SSID contains spaces, use a \$ instead of the space, e.g., **MY\$NETWORK** to represent **MY NETWORK**.

join # <num> - join a network from the scan list. <num> is the entry number in the scan list that is returned from the scan command. If network is security enabled you must set the pass phrase with the **set wlan phrase** command prior to issuing the **join** command.

- Example: **join # 1**

leave - disconnects from currently associated Access Point.

lites - causes the LEDs lights to start blinking. Issuing the command a second time stops the blinking.

lookup <string> - causes the module to perform a DNS query, where <string> is the host name for which to search.

- Example: **lookup serialio** - Searches for the host serialio.

open <addr> <port> - opens a TCP connection to the given IP port and address. If no arguments are provided, the device will attempt to connect to the stored remote host IP address and remote port number. <addr> can also be a DNS hostname and will be resolved if entered.

ping <g | h | i | addr> <num> - ping remote host. Default sends 1 packet. Optional <num> sends <num> pings at 10 per second.

- 1) **ping 10.20.20.12 10** - pings IP address 10 times

- 2) **ping g** - pings the gateway, the gateway IP address is loaded if DHCP is turned on, otherwise it should be set with the **set ip gateway <addr>** command
- 3) **ping h** - pings the stored host IP address, the host IP address can be set with the **set ip host <addr>** command
- 4) **ping i** - pings a known Internet server at www.neelum.com by first resolving the URL (proves that DNS is working and proves the device has internet connectivity)
- 5) **ping 0** - terminates a ping command

reboot - forces a reboot of the device (similar to power cycle).

scan <time> <P> - performs an active probe scan of access points on all 13 channels. Returns MAC address, signal strength, SSID name, security mode. Default scan time is 200ms / channel = about 3 seconds. **time** is an optional parameter; this is the time in ms per channel. For example, **scan 30** reduces the total scan time down to about 1 second. This command also works in ad-hoc mode. If the optional **P** parameter is entered, the module will perform a passive scan, and list all APs that are seen in passive mode.

sleep - puts the module to sleep mode. The module can come out of sleep mode by either sending characters over the UART or by using the wake timer.

time - sets the Real time clock by synchronizing with the time server specified with the time server parameters. This command sends a UDP time server request packet.

9 FILE IO Commands

del <name> <num> - deletes a file. Optional **<num>** will override the name and use the sector number shown in the **ls** command.

load <name> - reads in a new config file.

ls - displays the files in the system.

save - saves the configuration to "config" (the default file).

save <name> - saves the configuration data to a new file name.

boot image <num> - makes file **<num>** the new boot image.

ftp get <name> - retrieves a file from the remote FTP server. If **<name>** not specified, the stored ftp filename is used.

ftp update <name> - deletes the backup image, retrieves new image and updates the boot image.

10 Advanced Features and Settings

This chapter describes the advanced features of the WiSnap module. It describes the techniques to put the module in sleep, wake up from sleep and methods to open a TCP connection when awake. We also discuss the UART flow control, alternative GPIO functions and Real Time Clock.

The table below describes the possible methods of putting the module to sleep:

Method	Interface	Description
"sleep" command	UART	Get into command mode using \$\$\$ and issue the sleep command.
Sleep Timer	Internal RTC	Puts the module to sleep based on the set sys sleep <secs> command.

Drive GPIO9 High	GPIO8	The module sleeps as soon as GPIO8 is held high (4 μ s latency). To enable this feature, use the set sys trigger 0x20 command setting.
------------------	-------	---

To wake up the module from sleep, following options are available:

Method	Type	Description
Sensor Input (1.2VDC ONLY)	Sensor Pins	You can wake up the module on sensor pins 0-3 (1.2V ONLY). Use the set sys trigger <value> command to enable. Refer to section 10.2 for details.
Rx Pin (1.2VDC ONLY)	Rx pin via Sensor 0	The RX pin on the RN-134 is tied to Sensor Pin 0. Use the set sys trigger 1 command to wake up on RX data. NOTE: You may drop the first byte of UART data. A better way to wake up the module on CTS pin. Refer to section 10.3 for details.
CTS Pin (3.3VDC ONLY)	CTS pin via Sensor 1	The CTS pin on the RN-134 is tied to Sensor pin 1. Use the set sys trigger 2 command to wake up on CTS. Refer to section 10.3 for details.
Wake Timer	Internal RTC	Wakes up the module from sleep based on the set sys wake <secs> command.
FORCE AWAKE	FORCE AWAKE pin	Input pulse of at least 31 μ secs duration (3.3V ONLY) will wake up the module.

When the module wakes up from sleep, it takes a certain amount of time (in milliseconds) to initialize the internal hardware. During this time, any data that is sent to the WiSnap module over the UART will not be processed. You can monitor certain signals that indicate that the module is ready to accept data. These are described in the table below:

Method	Interface	Description
RTS transition	RTS pin	Once the WiSnap module wakes up, the RTS line goes HIGH. Once the system is ready, the RTS is driven LOW. This can be monitored by the micro controller.
Monitor GPIO4	Alternative GPIO functions	Set the alternative functions for GPIO 4, 5, and 6 (refer to section 10.5.1). Once the module wakes up and connects to an AP, GPIO 4 goes high. This indicates the module is ready to receive data over UART. Your micro controller can monitor GPIO 4.
Sensor power	Sensor power pin	You can configure the module to output Vbat, 3.3 V, or 1.2 V on the sensor power pin when it wakes from sleep, indicating it is ready to accept data.

Once the module is awake, you can open a TCP connection to a remote host in a number of ways described below. The remote host can be set using the following commands:

- 1) **set ip host <IP address>** or **set dns name <string>** - sets up the IP address OR URL of host
- 2) **set ip remote <port number>** - sets up the port number on which the host is listening
- 3) **save** - save settings in config file
- 4) **reboot** - reboots the module so that the settings take effect

Method	Type	Description
Auto connect	Internal RTC Timer	Connect out to the host at specific time intervals based upon the set sys autoconn <secs> command.
Open	UART	In command mode, you can issue the open command.
Connect UART data	UART mode 2	This mode is designed for the HTML client feature. Use the set uart mode 2 command to automatically connect out to host on UART data.
GPIO 5	Alternative GPIO functions	Set the alternative functions for GPIO 4, 5, and 6 (refer to section 10.5.1). Set GPIO 5 HIGH to trigger TCP connection, LOW to disconnect.

10.1 System Timers and Auto Connect Timers

The WiSnap module uses the Real Time clock (RTC) to generate timers. The RTC is active even when the WiSnap module is asleep. This makes it possible to put the module to sleep and wake up from sleep based on timer intervals using timers.

The WiSnap module has the following timers available:

- **Sleep Timer:** Used to put the WiSnap module to sleep
- **Wake Timer:** Used to wake the WiSnap module from sleep
- **Auto-connect Timer:** Used to automatically open a TCP connection
- **Idle Timer:** Used to automatically close a TCP connection

There are 2 timers that can be used to put the module to sleep, and perform a wake up. If the sleep timer is enabled, the module will automatically go into deep sleep low power mode once the timer counts down to 0. The sleep timer is disabled if the module has an IP connection, or the module is in COMMAND mode.

The sleep timer (which is the time the WiSnap is awake) is a 32 bit number of seconds so it can be as high as 1.19 million hours.


The wake timer (which is the time the WiSnap is asleep) is a 22 bit number of seconds so the maximum sleeping time is 1165 hours.

The sleep timer is set with: **set sys sleep <time>** - time = decimal in seconds. The wake timer will bring the module out of deep sleep.

The wake timer is set with: **set sys wake <time>** - time = decimal in seconds.

For example, if you wanted the module to wake up, join a network and be available to accept TCP connections for 30 seconds every two minutes you would set the timers as such:

- 1) **set wlan ssid my_net**
- 2) **set wlan passphrase my_pass set sys sleep 30**
- 3) **set sys wake 90 save**
- 4) **reboot**



The above diagram shows the transitions between the Sleep state and Awake state based on the sleep and wake timers.

10.1.1 UDP Sleep and Connection Timers

In UDP-only protocol mode (**set ip proto 1**), the autoconn timer is used as an auto-sleep timer.

Upon the start of transmission of the first UDP data packet this timer will count down, after which the module will go to sleep.

set sys autosleep <value> - UDP Only mode: sets the auto-sleep timer. Setting value=0 disables autosleep timer.

The UDP auto-sleep timer is set using two variables. The timer interval is a product of the autosleep value and the comm flush timer (in milliseconds). The timer is decremented every “product” milliseconds.

For example, if you need a UDP sleep timer of 40 milliseconds, you need to set the following variables:

set sys autosleep 4 - sets the autosleep value to 4

set comm timer 10 - sets the comm timer to 10 ms (default value)

The resulting UDP sleep timer will be $4 \times 10 \text{ ms} = 40 \text{ ms}$. You can also use a combination of autosleep = 2 and comm timer = 20 ms to achieve the same effect.

Using a minimum value of 2 (when the default flushtime=10 ms) is recommended to ensure that the UDP packet gets transmitted. For larger packets the value should be increased.

10.1.2 TCP Connection Timers

Opening a TCP Connection

In TCP-Client mode, the auto-conn timer controls the establishment of a socket connection. When set, the device automatically and periodically attempts to establish a connection each time the timer expires.

set sys autoconn <secs> - causes the module to periodically connect to the host. The timer <secs> determines how often to connect to the stored remote host. If set to 1, the module will only make one attempt to auto connect upon power up. If set to 2 or greater auto connect will re-open the connection after the connection is closed. Default=0 disables.

For auto connect timer to work, the remote host’s IP address and port number needs to be configured in the WiSnap module.

Closing the TCP connection

In TCP-Client AND TCP-Server mode (default mode), there is also a disconnect timer. This timer can be used to automatically close a TCP connection after a specified number of seconds with no transmit or receive data.

set comm idle <secs>

For example, to close the TCP connection after 5 seconds of inactivity, use the **set comm idle 5** command.

The default value of the comm idle timer is 0, never disconnect on idle.

10.2 Wake on Sensor Input

SENSE 0 to 3 inputs are available to wake the module from sleep. SENSE 0 to 3 pins have a small current source that is activated in sleep mode. This source is approximately 100nA, and will cause the input to float up to about 1.2VDC. If SENSE1, for example, is enabled, pulling the SENSE1 pin to GROUND will wake the device.

To enable these inputs to wake the module, use the command **set sys trigger <value>**. The value is a bit-mapped setting. To wake on sensor pin 2, use **set sys trig 4**, for example. Setting the value to 0 disables all sensors pins.

The table below describes the values to wake the module using individual sensor inputs.

Sensor Input Values

Wake on Sensor Input	Value	Command
0	1	set sys trigger 1

1	2	set sys trigger 2
2	4	set sys trigger 4

- **WARNING: Under no conditions should the voltage on any sensor input exceed 1.2VDC. Permanent damage to the module will result.**

Sensor inputs are rated 1.2VDC maximum. You must use a resistor divider when driving a sensor pin from the other 3V pins such as RX. A resistor divider network with a minimum of 24K in series and 10K to ground from the UART RX or CTS pin should be used.

An open drain FET is a good device to tie to the SENSE pin. The threshold is about 500mV. Additional pullup to 1.2VDC may be used if the circuit has an impedance (due to leakage current) of less than 5Mohms (500mv / 100nA). SENSE 0 to 3 pins that are not used should be left unconnected.

10.3 Wake on UART

When the module is in sleep mode, the UART itself is disabled. However, wake on UART can be accomplished by connecting the SENSE pins to the RX data or CTS pin (using the appropriate divider resistors mentioned above).

The WiSnap SuRFBoard has a built in resistor divider connecting SENSE 0 and SENSE 1 to RXD and CTS respectively. This allows wake on RX and CTS using a 3.3V signal.

- **WARNING: Do not apply 3.3V directly to SENSE 0 and SENSE 1. Under no conditions should the voltage on any sensor input exceed 1.2VDC. Permanent damage to the module will result.**
- **NOTE:** On WiSnap SuRFBoard **rev 2** the resistor pack connecting RX and CTS signals is not correctly connected to the sensors. To wake on UART RX place a jumper from pin 3 on the Evaluation board header to pin 2 on the sensor header. To wake on UART CTS place a jumper from pin 10 on the Evaluation board header to pin 3 on the sensor header.

To enable wake on RXD, use **set sys trig 1**.

It should be noted that the first (or possibly multiple) byte sent into the module will likely be lost, so the designer should take care to send a preamble byte to wake up the module before sending valid data bytes. A better way to do this is to use the CTS input to wake the module, and wait until it is ready to accept data. To enable this, use **set sys trig 2**.

10.4 UART Receiver, RTS/CTS Hardware Flow Control

The UART receive buffer is approx. 1500 bytes, and at lower baud rates (less than 115K) the system can send data over TCP/IP without the need for flow control.

Depending on the frequency and quantity of data begin sent, the **set comm** parameters will optimize Wi-Fi performance by specifying when the system sends IP packets. To minimize latency and TCP/IP overhead use the flush size or match character to send data in a single IP packet. In most cases you will want to set the flush timer to a large number to avoid fragmentation. For high throughput cases increase the UART baud rate, set the flush size to 1460 and flush timer to a large value so full IP packets are sent.

You can control the packet forwarding 3 ways:

- **set comm match <value> | <hex>** - This command sets the match character, where <value> is a decimal number from 0 to 127 or a hex number from 0 to 7F. When this configuration option is set, the module sends an IP packet each time the match character appears in the data. You enter <value> either as the decimal (e.g., 13) or hex (e.g., 0xd)

equivalent of the ASCII character. Setting the match character to 0 disables matching. Each time the match character is seen an IP packet will be sent. For example, **set comm match 0xd** forwards once a 0xd hex character is seen.

- **set comm size <value>** - This command sets the flush size in bytes, where <value> is a decimal number from 0 to 1,420 (at 9600 baudrate). When this configuration option is set, the module sends an IP packet each time <value> bytes are received. It is recommended that you set this value as large as possible to maximize TCP/IP performance. This sets the flush size, the size is the number of bytes received before forwarding. Maximum value = 1460 bytes which is the size of a single Ethernet frame.
 - **NOTE:** To optimize the link, this value is set automatically when the baud rate is set. It is assumed that higher baud rates equate to more data, hence the flush size is increased.
- **set comm time <value>** - This command sets the flush timer, where <value> is a decimal number representing milliseconds. When this configuration option is set, the module sends an IP packet if no additional bytes are received for <value> ms. Setting this value to 0 disables forwarding based on the flush timer. This is used to make sure that any partial data sitting the RX buffer if no additional data is seen for "value" milliseconds. For example **set comm time 1000** would wait for 1 second after no data was sent.

If the module will be sending more than a few hundred thousand bytes in a single transaction, you should enable hardware flow control. Your hardware must actively monitor the CTS pin. Flow control is not enabled by default; you set it with the **set uart flow 1** command.

It is possible to operate higher baud rates (greater than 115K) without flow control if packets are uniform and an application protocol is used to ensure that each packet data is delivered on the remote side before the next packet is sent.

However, given the uncertainty of packet delays in a TCP/IP network and the effects of interference and retries inherent in wireless networks, flow control is usually required whenever large, contiguous quantities of data are being written to the UART to guarantee no data is lost.

10.5 Setting GPIO direction, Alternate Functions and Disabling LEDs

The direction of the GPIO can be controlled with the GPIO mask using the **set sys mask <value>** command to set the GPIO pin direction. Value is entered as a hex number. If you need to set only one bit in the mask you need to read, mask and set the value. Otherwise you will over write any previous GPIO settings.

The hex value represents a bit mask that controls each pin where 1 = output and 0 = input. For example, **set sys mask 0x0** sets all pins to input.

To set only GPIO 6 and 7, for example, you would enter **set sys mask 0xc0**.

The default mask for WiSnap = 0x20f0, which has GPIO 13, 8, 7,6,5,4 as Outputs. GPIO 0-3 are used internally on the module. GPIO 4, 5, 6 are LEDs. GPIO 9 is reserved as the ARM factory reset/ad-hoc mode, (read at power up) and otherwise general purpose input detect pin. GPIO 10, 11 are the UART RX, TX pins and TX does not need to be masked as an output. GPIO12 is CTS (input) if used. GPIO13 is RTS (output) if used.

The LEDs on the WiSnap SuRFBBoard (M1) are connected to GPIO 4, 5 and 6. To disable the LEDs, enter **set sys mask 0x20d0**.

- **NOTE:** The Yellow, Red and Green LEDs can be turned off. The Blue LED on the Surf board is the power LED and cannot be turned OFF.

The **get sys** command will show the setting of the GPIO mask.

```
<2.20> get sys
```

```
SleepTmr=0
```

```
WakeTmr=0
```



```

Trigger=0x1
Autoconn=0
IoFunc=0x0
IoMask=0x21f0
PrintLvl=0x1

```

The table below shows the usage of the GPIO pins with their default state and functionality:

Bit	Signal Name	RN-131 Default State	RN-171 Default State	Default Function
0	GPIO0	N/A	N/A	-
1	GPIO1	N/A	Input	Unused
2	GPIO2	N/A	Input	Unused
3	GPIO3	N/A	Input	Unused
4	GPIO4	Output	Output	Green LED
5	GPIO5	Output	Output	Yellow LED
6	GPIO6	Output	Output	Red LED
7	GPIO7	Output	Output	Blue LED
8	GPIO8	Input	Output	Unused
9	GPIO9	Input	Input	Ad hoc mode and factory reset
10	GPIO10	Output	Output	UART TX
11	GPIO11	Input	Input	UART RX
12	GPIO12	Input	Input	Throttles the transmitter if hardware flow control is enabled. Driving this pin low enables transmitter; driving this pin high disables it.
13	GPIO13	Output	Output	This pin goes high on power up and goes low when the system is ready. If hardware flow control is enabled, this pin toggles high to indicate the RX buffer is full
14	GPIO14	N/A	Input	-

- **NOTE:** The Blue LED is connected to GPIO7 on the WiSnap AAA. The Blue LED is not connected to GPIO7 on the WiSnap SuRFBBoard (M1). It is not possible to power off the Blue LED on the SuRFBBoard because it is connected directly to power.

10.5.1 Setting the alternate GPIO functions

The defaults for GPIO 4, 5, 6 are to control the LED functionality. This default functionality can be overridden to allow user programmable IO or alternate IO functionality by using the **set sys iofunc <value>** command. Value is entered as a hex number.

The hex value represents a bit mask that controls each bit in the <value> represents a particular GPIO pin. If a bit is 0, then that GPIO is driven/read by the firmware per the default function.

The IO function <value> is encoded as such:

Bit	Signal Name	Direction	Function
0	GPIO4	Output	Disable the LED function so the I/O can be used as a GPIO pin.
1	GPIO5	Output	Disable the LED function so the I/O can be used as a GPIO pin.
2	GPIO6	Output	Disable the LED function so the I/O can be used as a GPIO pin.
3	Unused	-	-
4	GPIO4	Output	This pin goes high after the module has associated/authenticated and has an IP address.
5	GPIO5	Output	Set this pin high to trigger a TCP connection and low to disconnect.
6	GPIO6	Output	This pin goes high when the module is connected over TCP and low when disconnected.

- **NOTE:** Bits 0-3 are mutually exclusive with the bits 4-6. i.e. 0x77 is an illegal value.

If the LEDs are disabled using bits 0, 1, 2 above, you can then use the **show i** command to read these GPIO. For example **show i** will return **Port=30**.

For example, to use the alternate functions of the LEDs, the sequence of commands would be:

- 1) **set sys iofunc 0x70** - enable alternate function for GPIO 6, 5 and 4
- 2) **save** - store configuration
- 3) **reboot** - reboot the module

Another example uses GPIO7 to drive the DTR line on the WiSnap AAA Male (see section 2.6.4 for necessary jumper configuration):

- 1) **set sys iofunc 8** - sets PIO7 to be an alternate IO function
- 2) **save** - store configuration
- 3) **reboot** - reboot the module

- **set sys output 0x80 0x80** - drives PIO7 (DTR) HIGH
- **set sys output 0 0x80** - drives PIO7 (DTR) LOW

- **NOTE:** Currently, the alternative GPIO functions are not available in ad-hoc mode.

10.5.2 Controlling connections with GPIO.

In embedded applications it is useful to monitor and control the status of the TCP/IP connection. This can be done by using the alternate function for GPIO-5 and GPIO-6.

With the alternate function for these GPIO set, the module will connect to the stored remote host IP address and port when GPIO-5 is driven high and disconnect when driven low.

The TCP/IP connection status can be monitored by reading GPIO-6, high = connected, low = not connected.

Here is how to set the WiSnap module to connect using GPIO-5 and GPIO-6:

- 1) **set ip host <addr>** - set the IP address of the remote host
- 2) **set ip remote <port>** - set the IP port of the remote host
- 3) **set sys iofunc 0x60** - set alternate function for GPIO-5 and GPIO-6
- 4) **save** - store configuration
- 5) **reboot** - the module must be rebooted for the alternate settings to take effect

On the remote host run your application or other software that opens and listens on the <port>. Connect GPIO-5 to your embedded processor or other control signal. When GPIO-5 is driven high a connection will be attempted. When drive low the connection will be closed.

Warning: Be sure to not to drive the GPIO with more than 3.3 VDC or permanent damage to the module will occur.

If the connection to the remote host is successful GPIO-6 will go high. If the COMM OPEN and REMOTE strings are set you should see the *OPEN* messages on the UART and the *HELLO* at the remote host.

10.6 Setting Debug Print levels

There are a number of print functions that can be enabled to assist in debugging the operation and status of the module. The following command is used to control these printouts:

- **set sys printlvl <value>** - sets additional print functions. Value is a bit-mapped register that controls which printout messages are sent to the UART. See Section 5.8, **set sys** parameters for more information.

10.7 Scan Output Format

You enable the scan output using the **set sys printlvl 0x4000** command. The scan output format differs, depending on the firmware you are running.

Firmware Version 2.36 & 2.45

Firmware version 2.36 and 2.45 support a comma-delimited scan output format, which a microprocessor can use to parse the RSSI information. The scan command output format is:

Index	Channel	RSSI	Security Mode	Capabilities	WPA Configuration	WPS Mode	MAC address	SSID
-------	---------	------	---------------	--------------	-------------------	----------	-------------	------

Where:

Field	Value
Index	2 character, decimal
Channel	2 character, decimal
RSSI	2 character, decimal (negative number)
Security mode	2 bytes (see Table Security Modes below)
Capabilities	Bit-mapped 4 hex bytes (see Table Capabilities Bit Mask Values below)
WPA Configuration	Bit-mapped 2 hex bytes (see Table WPA Bit Mask Values below)
WPS Mode	Bit-mapped 2 hex bytes (see Table WPS Bit Mask Values below)
MAC address	Address
SSID	Up to 32 chars

- **NOTE:** The string **END** is added at the end of the scan data.

The following example shows the output format:

```
Scan:Found 3
01,01,-59,04,1104,28,c0,20:4e:7f:08:df:85,sdef
02,03,-64,02,1104,28,00,00:30:bd:9b:49:22,basement
03,10,-71,04,3100,28,00,90:27:e4:5d:fc:a7,UMONEY
END:
```

Table: Security Modes

Number	Description
0	OPEN
1	WEP (64 or 128)
2	WPA1
3	MIXED
4	WPA2
5	Enterprise WEP
6	Enterprise WPA1
7	Enterprise WPA mixed
8	Enterprise WPA2
9	Enterprise NO security

Table: Capabilities Bit Mask Values

Bit Mask Value	Description
0004	Short slot time
0100	ESS (infrastructure mode)

0200	IBSS (ad hoc mode)
1000	Privacy (secure with WEP or WAP)
2000	Short preamble

Table: WPA Bit Mask Values

Bit Mask Value	Description
04	WPA_UNICAST_TKIP
08	WPA_UNICAST_AES_CCMP
10	WPA_BROADCAST_TKIP
20	WPA_BROADCAST_AES_CCMP

Table: WPS Bit Mask Values

Bit Mask Value	Description
02	WPS_PushButton_ACTIVE
40	WPS_SUPPORTED
80	WPS_PushButton_SUPPORTED

Firmware Version 2.22 through 2.30

Firmware version 2.22 through 2.30 supports a comma-delimited scan output format, which a microprocessor can use to parse the RSSI information. The scan command output format is:

Row Count	Channel	RSSI Value (dBm)	Security Mode	Capabilities	Access Point MAC Address	SSID
-----------	---------	------------------	---------------	--------------	--------------------------	------

Example output from the scan command output is shown below:

```
SCAN:Found 5
01,01,-53,00,0200,1a:fc:90:e5:a5:37,QTDFW
02,01,-59,04,3104,00:15:f9:38:bd:b0,SensorNet
03,11,-72,04,3104,00:16:b6:45:63:98,CoolBox
04,11,-50,02,3100,00:18:02:70:7e:e8,airlink-11
05,11,-69,04,3100,00:14:6c:1f:f7:5e,ap-ssid-change-me
```

The security mode field for this scan format is described below:

Security Mode	Open	WEP	WPA-PSK	WPS2-PSK	WAP-Enterprise	WPA2-Enterprise
Code	0	1	2	4	6	8

10.8 UART Heartbeat Messages

In firmware version 2.22 and higher, the module can output UART heartbeat messages. The bit-mapped message is output periodically while the module is in data mode and not connected to a remote host. Messages are not output while in command mode. The heartbeat message encodes the module's state for the embedded microprocessor. Based on the heartbeat message, the microprocessor can choose to change the configuration by going into command mode.

To enable the UART heartbeat messages, use the **set sys printlvl 0x10** command. The output of this mode is:

***8b30*8b30*8b30....**

Table: Output Bit Format

Bit	15..14	13..12	11..8	7..6	5	4	3..0
Function	Fixed	RESERVED	Channel	RESERVED	Authentication	Association	TCP Status
Value	2 = Access point	Unused	0-13	Unused	1 = OK	1 = OK	0 = Idle

	mode 3 = Ad hoc mode						1 = Connected 3 = No IP 4 = Connecting 5 = Challenge for password
--	-------------------------	--	--	--	--	--	---

10.9 Using the Real Time Clock Function

The module's real-time clock keeps track of the number of seconds since the module was powered on and the actual time when the module synchronized with the sNTP time server. By default, the module keeps track of up time but does not synchronize with the time server because this synchronization requires the module to be associated with a network that can access the sNTP server. The real-time clock reads the time in seconds since 1970, which corresponds to the UNIX time.

In firmware version 2.23 and higher, you can set the RTC value in seconds using the **set time rtc <value>** command.

The default sNTP server is:

ADDR=129.6.15.28:123
ZONE=7 (GMT -7)

Use the **show time** command to see the current time and uptime as shown below:

```
<2.23> show t
Time=08:43:10
UpTime= 10 s
```

To set the time, use the **time** command:

```
<2.23> show t
Time NOT SET
UpTime= 8 s
<2.23> time
<2.23> show t
Time=08:51:31
UpTime= 15 s
```

➤ **NOTE:** The module must be associated with a network for the module to contact the sNTP server.

The module can also be configured to get the time whenever it powers up using the **set time enable 1** command. If you set the time enable to a value greater than 1, the module pulls the time continuously every <value> minutes.

For example, to configure the module to get time upon power up, see the following example:

```
<2.23> set time enable 1
AOK
<2.23> get time
ENA=1
ADDR=129.6.15.28:123
ZONE=7
```

To view a complete listing of the time variable, use the following command:

```
<2.23> show t t
Time=09:02:10
UpTime=653 s
RTC=1293567548
Restarts=1
```

Wake=6
RAW=2345ab

- **NOTE:** The RAW value is the 64-bit hex RAW value of the RTC, which ticks at 32,768 Hz.

10.10 Time Stamping Packets

This feature can be used to automatically append 8 bytes to a TCP or UDP packet.

set ip flags 0x87 - enables timestamp and keeps other default settings

TIME STAMP (MSB to LSB)

User's TCP or UDP packet Data	63-56	55-48	47-40	39-32	31-24	23-16	15-8	7-0
----------------------------------	-------	-------	-------	-------	-------	-------	------	-----

The 8 bytes represents the 64-bit raw value of the real-time clock register. The data is appended before calculating the TCP checksum so that the data passes through the TCP stack correctly. This register counts at 32,768 Hz. If the timeserver function is enabled, the RTC should accurately reflect the real time. This register also counts when the module is in sleep mode.

11 Sending data using UDP

11.1 Overview

UDP is a connectionless protocol: there is no initial handshaking between the hosts to set up the UDP connection and the receiver does not send an acknowledgement when it receives UDP packets. Therefore, UDP is an unreliable protocol because there is no guarantee that the data will be delivered correctly. However, because it is connectionless, UDP is suited for applications that cannot tolerate too much latency but can tolerate some errors in the data, e.g., video transmission.

To use UDP with the module, you must enable the UDP protocol using the **set ip proto 1** command. You must also specify the remote host's IP address and the local and remote port number that you will use for UDP communications. The following example shows the commands you use to enable UDP data transfer.

Associate to a network:

- **set wlan ssid <string>** - set the network name
- **set wlan phrase <string>** - set the passphrase for WPA and WPA2 modes

Set up the protocol and port number:

- 1) **set ip proto 1** - enable UDP as the protocol
- 2) **set ip host <ip address>** - set the IP address of remote host
- 3) **set ip remote <port>** - set the remote port number on which the host is listening
- 4) **set ip local <port>** - set the port number on which the WiSnap module will listen
- 5) **save** - saves the settings in config file
- 6) **reboot** - reboots the module so that the above settings take effect

- **NOTE:** If you attempt to send data by physically typing characters on the keyboard or if your microcontroller is not sending data fast enough, the WiSnap module will send out packets with less data bytes. To avoid this, set the flush timer to a higher value. By default, it is set to 10 milliseconds. You can choose to either disable forwarding based on flush timer (use "set comm. time 0") or set it to a higher value (e.g. set comm. time 2000).

Since UDP is a connectionless protocol, data will start flowing as soon as the module is rebooted. Unlike TCP, it is not required to do an "OPEN" for the connection to be established. The WiSnap module acts like a data-pipe, so the UART data will be sent

over the Wi-Fi link via the UDP protocol (in this case) and the data coming over the Wi-Fi link (via UDP protocol in this case) will be sent to the UART.

11.2 UDP Auto Pairing

UDP auto pairing feature temporarily stores the Host IP address of the first remote device that send a UDP packet into the module. This host IP address is stored in the RAM, which will not survive a sleep or power cycle.

This feature allows the WiSnap module to echo back to any client that sends a UDP packet. To use this feature, the host IP addresses and set the ip flags.

- **set ip host 0.0.0.0**
- **set ip flags 0x80**

11.3 UDP Retry

This feature adds a level of reliability to the UDP protocol without adding the complete overhead of TCP protocol. When enabled, the module waits for a response on every UDP packet sent, (any UDP packet coming back in). If the response packet is not received by approximately 250 ms, the same UDP packet is sent out.

This continues until either:

- A UDP response is seen, or
- A new UDP packet is sent from the module and is acknowledged

To enable this feature, use **set ip flags <value>**.

11.4 Using the UDP Broadcast function

The WiSnap module can be setup to automatically generate UDP broadcast packets. This is useful for a number of reasons:

1. Some Access Points will disconnect devices that sit idle and don't send any packets after a time. Using the UDP broadcast informs the AP that WiSnap is alive and wants to stay associated.
2. This feature can be used by application programs to auto-discover and auto configure the WiSnap module. If an application is listening for the UDP broadcast, a number of useful parameters are present in the package that can be used for auto-discovery. For example, the IP address and port number of the WiSnap are both apart of the packet, and thus the WiSnap can be connected to and configured remotely with this information.
3. The MAC address of the associated AP, channel, and RSSI value are available in this packet, thus enabling a simple location and tracking based function.

By default the WiSnap module now sends out a UDP broadcast to 255.255.255.255 on port 55555 at a programmable interval. The broadcast address, port and interval are set using the **set broadcast** commands.

- **NOTE:** You can send the module's sensor data out via UDP broadcast. The analog-to-digital convertor is 14 bits on a 400 mV signal, which translates to about 24 microvolts (0x61A80 in hex). When you use the **show q** command in command mode, the module displays the raw readings. However, for HTTP web posting and UDP broadcast packets, the module shifts the reading by 4 bits (which is a divide by 16) resulting in a 16-bit number. Therefore, if you want the actual voltage sampled, you must take the 16-bit number and shift it left by 4 bits to get the number of microvolts. If you must have the value in millivolts (and do not need high accuracy), right shift by another 6 bits, which is the same as dividing by about 1000.

The format of the packet is: 110 bytes of data:

AP MAC address	Chan	RSSI	Local TCP port	Real Time Clock	Battery Voltage	GPIO pins	Time of day	Version and datecode	User DEVICEID	Boot time	Sensor pins
----------------	------	------	----------------	-----------------	-----------------	-----------	-------------	----------------------	---------------	-----------	-------------

Bytes	Size	
0-5	6	MAC address of AP that we are Associated with (for location)
6	1	Channel we are on
7	1	RSSI
8-9	2	local TCP port# (for connecting into the WiSnap device)
10-13	4	RTC value (MSB first to LSB last)
14-15	2	Battery Voltage on Pin 20 in millivolts (2755 for example)
16-17	2	Value of the GPIO pins
18-31	13	ASCII time
32-59	26	Version string with date code
60-91	32	Programmable Device ID string (set option deviceid <string>)
92-93	2	Boot time in milliseconds
94-110	16	Voltage readings of Sensors 0 through 7 (enabled with set opt format <mask>)

- **NOTE:** To add sensor data to the UDP broadcast message, the sensors have to be enabled using the sensor mask. **set q sensor 0xff** enables all sensors.

12 Joining Networks and Making Connections

Configuring the module to make connections is a two set process. First you need to associate with an access point (AP) and second you need to open a connection.

To configure the module over the Wi-Fi link is a chicken and egg problem. The module must be associated to a network to connect to it and program the network settings. This problem can be solved by configuring the module from the UART or over the air using ad-hoc mode.

If configuring the module using ad-hoc mode, see section 15. Once in ad-hoc mode open up a telnet window on IP address 169.254.1.1 port 2000.

If configuring the module using the UART mode either using the RS232 or development board, open a terminal emulator on the COM port associated with that device. The default baud rate is 9600, 8 bits no parity.

12.1 Associate with a network access point

From within the terminal window, put the WiSnap module into command mode by typing **\$\$\$** in the terminal window. You should get CMD back confirming you are in command mode.

Type **show net** to display the current network settings.

```
CMD
show net
SSid=TheLoft
Chan=6
Assoc=OK
DHCP=OK
Time=Fail
Links=1
<2.03>
```

Now finding all available networks with the **scan** command


```
CMD
scan
<2.03>
Found 6
```

Num	SSID	Ch	RSSI	Sec	MAC Address	Suites	
1	roving1	01	-64	Open	00:1c:df:4f:45:9e	104	4
2	NETGEAR	01	-58	Open	00:22:3f:6b:95:42	104	0
3	07FX12018434	06	-73	WEP	00:18:3a:7e:71:d7	1104	0
4	TheLoft	06	-51	WPA2PSK	00:0c:41:82:54:19	AESM-AES 1100	0
5	airlink-11	11	-53	WPAv1	00:18:02:70:7e:e8	TKIPM-TKIP 3100	ac
6	sensor	11	-52	Open	00:1c:df:cc:aa:d8	100	1

If the network you're connecting to is open, you can simply use the **join** command to associate with the access point. From the scan list above you can see that roving1 is an open network access point. Type **join roving1** to associate with an access point.

```
CMD
<2.03> join roving1
Auto-Assoc roving1 chan=1 mode=OPEN SCAN OK

<2.03> Associated!
DHCP in 1ms: Renew: 86400 s
IF is UP
DHCP=ON
IP=10.20.20.62:2000
NM=255.255.255.0
GW=10.20.20.20
HOST=0.0.0.0:2000
PROTO=2
MTU=1460
bind=10
listen FAIL
```

You could also have specified the roving1 access point by using the command **join # 1**

If the access point is security enabled you will need to set the pass phrase prior to issuing the **join** command. The RN-131G module will attempt to inquire and determine the security protocol of the access point so you do not have to set the authentication mode. To set the pass phrase for WPA use the command **set wlan phrase <string>**. For WEP set the key using the **set wlan key <num>** command.

Once you have successfully associated to the network the access point SSID is stored. This along with the pass phrase can be saved to the config file so the module can associate with the network each time it is booted up.

12.2 Making Connections

To make a connection into the module simply open an IP socket and connect to the IP address of the module. Telnet is a simple way to test this connection. From in Telnet type **open <addr> <port>**. In the example above the telnet command you look like **open 10.20.20.62 2000**. Once open you can type characters into the UART window and see them on the Telnet window or vice versa.

To make a connection from the module you will need IP address and port number of your server application. A simple program to test this functionality is a COM port redirector. This software opens an IP port and transfers all data it receives to a specified COM port on your machine. A free com port redirector program is available from Pira at <http://www.pira.cz/eng/piracom.htm>

After installing and starting this program, note the IP address of the machine it is running on. This can be found by running ipconfig in the Microsoft command window.

With the WiSnap module in command mode, type **open** *<addr>* *<port>*. The server will report the connection is open and you can type characters into the UART window and see them on the server window or vice versa.

12.3 Setting up Automatic Connections

Some applications require the module to connect to a remote server, send data, and then disconnect automatically upon power up (or wakeup). You can configure the module to perform this functionality automatically.

Set the network SSID and security, and **set autojoin** to 1. When the module wakes up or is powered on, the auto-connect timer causes the module to attempt a connection to the stored remote IP address and port. The sleep timer does not decrement while this connection is open and the idle timer does not decrement while data is flowing. When data stops for 5 seconds the connection is closed; the sleep timer puts the module in deep sleep. The wake timer begins the cycle again one minute later.

- **NOTE:** You can also use ad hoc mode (**autojoin** 4); however, there will be a delay connecting to the ad hoc network from the remote computer. Therefore, make the sleep timer large enough to allow the network to get set up and the auto-connect to establish a TCP connection.
- Example: Automatic Connection
 - **set ip host** *<address>* - set up the remote machine's IP address
 - **set ip remote_port** *<value>* - set up the remote machine's IP port
 - **set sys autoconn** 1 - automatically connect when ready
 - **set com idle** 5 - disconnect after 5 seconds with no data activity
 - **set sys sleep** 2 - sleep 2 seconds after connection is closed
 - **set sys wake** 60 - wake up after 1 minute of sleep
 - **set uart mode** 2 - use UART data trigger mode, which causes the module to make a TCP/HTTP connection upon incoming UART data (supported in firmware version 2.19 and higher)

12.4 Controlling Connections using GPIO5 and GPIO6

You can use GPIO5 to control the TCP connection. After you configure the pin with the **set sys iofunc** command, the module attempts to connect to the stored IP address and port when GPIO5 goes high and disconnects when GPIO5 goes low.

Similarly, you can monitor the connection status by reading GPIO6. When it goes high, the connection is open; when it goes low, the connection is closed. Use the command **set sys iofunc** command to enable GPIO6.

- Example: Use GPIO5 & GPIO6 to Control Connections
 - **set sys iofunc** 0x20 - enable GPIO5
 - **set sys iofunc** 0x40 - enable GPIO6

12.5 Using DNS settings

The module contains a built-in DNS client. If you do not specify the host's IP address, (i.e., it is set to 0.0.0.0), the module uses DNS protocol. When you set the host name using the **set dns name** *<string>* command, the module automatically attempts to resolve the host address. When the address is resolved, the module connects automatically.

- Example: Use DNS

- **set dns name** *myserver* - sets the DNS host name of the TCP/IP connection to “myserver”. Once the address is resolved an automatic connection will be made.
- To manually lookup the IP address of a host, use this command:
 - **lookup** *<string>* - string is the hostname.

12.6 Utilizing the Backup IP address/connect function

The module contains a feature for auto-retry and redundancy. If the host’s first IP address connection fails, the module uses the backup IP (if set). If this fails (or is not set), the module uses the first DNS name. If this fails (or is not set), the module uses the backup DNS name (if set).

To set the backup IP address, use: **set ip backup** *<address>*

To set the backup DNS name, use: **set dns backup** *<string>*

13 Using HTML Client Feature

The WiSnap module has a built in HTML client. When enabled, the WiSnap module is capable of getting or posting data to a web server. Using the HTML client, it is now possible to post serial and/or sensor data to the host web server. This feature make is possible to provide Wi-Fi capabilities to applications such as GPS units, remote sensors, weather station, etc.

- Example: User wants to retrieve data from web server with this format:
 - <http://www.webserver.com/ob.php?obvar=WEATHER>
- **Settings:**
 - **set ip proto 18** - enable html client
 - **set dns name** **www.webserver.com** - name of your web server
 - **set ip address 0** - so WiSnap will use DNS
 - **set ip remote 80** - standard web server port
 - **set com remote 0** - turn off the REMOTE string so it does not interfere with the post

To make the connection the command would be **open** or inline you can send **open www.webserver.com 80**.

The user’s microprocessor should write to the UART:

GET /ob.php?obvar=WEATHER \n\n where the \n is the LINEFEED character decimal 10 or hex 0xa. Two linefeeds are required so the web server knows the page is complete.

- **NOTE:** Some web servers require a carriage return and linefeed to indicate that the page is complete. In this case, use **\r\n** at the end of the string instead of **\n\n**.

13.1 Built-in HTML Client Modes

WiSnap can be setup to automatically post data to and get data from a web server without any external HOST CPU. The advanced web features are enabled using the **set option format** *<flag>* command. This is a bit mapped register. The functions of the bits are described in the table below:

set option format *<flag>* Bitmapped value.

Value	Wake Reason
0	Undefined
1	Power on or hardware reset (battery install or power up)
2	Sleep (wake when the sleep timer is expired)
3	Sensor
4	Undefined
5	Button (WiSnap-AAA serial adapter only)
6	Software reboot
7	Watchdog

- Example:
 - **set option format 1** - automatically send an HTML data header
 - **set option format 7** - append sensor data in ASCII hex format
 - **set option format 11** - append all key value pairs to the sensor data

13.2 Automatically periodically connect to web server

The WiSnap module can be setup to automatically post data to a web server using the **set sys auto <value>** command, where <value> is a decimal number representing seconds. For example, the WiSnap module can be configured to connect to the web server every 10 seconds by using the **set sys auto 10**.

The example below illustrates the commands to configure WiSnap for connecting to the web server every 30 seconds.

- 1) **set com remote GET\$/ob.php?obvar=WEATHER** - setup the string
 - 2) **set sys auto 30** - auto connect every 30 seconds
 - 3) **set option format 1** - auto send header once connection is opened
 - 4) **set ip proto 18** - turn on HTTP mode=0x10 + TCP mode = 0x2
- **Note (1):** when HTTP mode is set, the WiSnap automatically appends the \n\n to the end of the packet.
 - **Note (2):** if the html header contains spaces, the \$ is required when entering the string. Space is the command delimiter. When WiSnap command parser sees \$ it will convert this to a SPACE character.

13.3 Automatically connect to web server on UART data

WiSnap supports a mode in which it can connect to the web server when it receives UART data. In this mode, connection to the web server will be triggered on UART data.

- Example:
 - **set ip proto 18** - turn on HTTP mode=0x10 + TCP mode = 0x2
 - **set dns name www.webserver.com** - name of your web server
 - **set ip address 0** - so WiSnap will use DNS
 - **set ip remote 80** - standard web server port
 - **set com remote GET\$/userprog.php?DATA=** - sample server application
 - **set uart mode 2** - automatically connect using data TRIGGER mode

Then when the serial UART data comes in, WiSnap auto connects to the web server, and will automatically send **GET /userprog.php?DATA=<users serial data> \n\n**

- **NOTE:** If you attempt to send data by physically typing characters on the keyboard or if your microcontroller is not sending data fast enough, the WiSnap module will send out small packets of data (It will send out many packets of small MTU size). To avoid this, set the flush timer to a higher value. By default, it is set to 10 milliseconds. You can extend the flush to a higher value (e.g. **set comm. time 5000**).

13.4 Posting binary data:

Web servers expect ASCII data, so if the User data is binary, WiSnap can convert binary data to ASCII format before sending it to the web server.

- Example:
 - **set ip proto 18** - turn on HTTP mode=0x10 + TCP mode = 0x2
 - **set dns name www.webserver.com** - name of your web server
 - **set ip address 0** - so WiSnap will use DNS
 - **set ip remote 80** - standard web server port
 - **set com remote GET\$/userprog.php?DATA=** - sample server application
 - **set option format 1** - converts user binary data in ASCII hex format

If incoming UART data = 6 bytes of binary data with hex values 0x01 0xAB 0x03 0xFF 0x05 0x06 WiSnap will send this string to the web server: **GET /userprog.php?DATA=01AB03FF0506 \n\n**

13.5 Auto posting sensor data:

WiSnap module can send the value of the GPIO and sensor pins:

The data will come as 18 bytes of ASCII HEX: *<2 bytes GPIO><channel 0 thru 7 sensor data>*

- **set ip proto 18** - turn on HTTP mode=0x10 + TCP mode = 0x2
- **set dns name www.webserver.com** - name of your web server
- **set ip address 0** - so WiSnap will use DNS
- **set ip remote 80** - standard web server port
- **set com remote GET\$/userprog.php?DATA=** - sample server application
- **set q sensor 0xff** - sets WiSnap to sample all 8 sensor channels
- **set sys auto 30** - auto make the connection every 30 seconds
- **set option format 7** - send the header plus the sampled binary data converted to ASCII format

The Resulting string sent to the server will be **GET /userprog.php?DATA=0F3000001111222233334444555566667777\n\n**

For the above example, the data format is listed in the table below:

2 Bytes GPIO	Channel 0	Channel 1	Channel 2	Channel 3	Channel 4	Channel 5	Channel 6	Channel 7
0F30	0000	1111	2222	3333	4444	5555	6666	7777

13.6 Examples using the HTML client

- **Example #1: Auto posting sensor data:**


In this example, we will connect to the web server at www.rovingnetworks.com/mike.php?ID and send data "ID=1234" every 60 seconds. We will also append the sensor data to the "ID=1234".

Set the network connections as described above. The other parameters that we need to set are described below:

- 1) **set dns name www.rovingnetworks.com** - set up the URL of the server
- 2) **set ip host 0** - instructs RN-370 to use DNS address of host server
- 3) **set ip remote 80** - standard web server port
- 4) **set ip proto 18** - enable HTTP and TCP protocols
- 5) **set com remote GET\$/mike.php?ID=1234** - set up the string
- 6) **set sys auto 10** - auto connect every 10 seconds
- 7) **set option format 7** - send header and sampled binary data converted to ASCII
- 8) **set option sensor 0xFF** - sets sensor mask to sample all channels
- 9) **save** - save the configurations in config file
- 10) **reboot** - reboot so that the settings take effect

Result:

You will receive a 200 OK returned from the web server as seen in the screenshot below:



Example #2: Posting UART data to web server

The WiSnap module is capable of auto posting serial UART data in ASCII or Binary format. In this example we will configure the WiSnap module such that when the serial UART data comes in, the WiSnap will connect and automatically send data to the web server in the following format: **GET /mike.php?ID=<user serial data> \n\n**

The other parameters that need to be set are described below:

- 1) **set dns name www.rovingnetworks.com** - set up the URL of the server
- 2) **set ip host 0** - instructs WiSnap to use DNS address of host server
- 3) **set ip remote 80** - standard web server port
- 4) **set ip proto 18** - enable HTTP mode = 0x10 and TCP = 0x20
- 5) **set com remote GET\$/mike.php?ID=** - set up the string

- 6) **set sys auto 10** - auto connect every 10 seconds
- 7) **set option format 1** - send an HTML header
- 8) **set uart mode 2** - automatically connect using data Trigger mode
- 9) **save** - save the configurations in config file
- 10) **reboot** - reboot so that the settings take effect

With the above settings enabled, the WiSnap module will connect out to the web server every time it receives data on the RX line. Serial data is sent to the host web server according to the flush timer and the flush size.

- **NOTE:** You cannot append the sampled sensor data to the UART data. Enabling “option format 7” along with **set uart mode 2** will result in erroneous data being sent.

14 Firmware Upgrade over FTP

The WiSnap module has a file system for storing firmware, web pages and config files. Use the **ls** command to view files. File size is displayed in sectors and the active boot image is identified in the final message.

FL#	SIZ	FLAGS	
11	18	3	WiSnap_GSX-2.21
29	1	10	config
190 Free, Boot=11, Backup=0			

Multiple firmware images and config files can be stored on the module file system.

- **NOTE:** The Flash File system is used only to store firmware and configuration files. Currently the file system cannot be used to store data files.

14.1 FTP Upload and Upgrade

WiSnap contains a built in FTP client for getting files and updating the firmware. The client uses passive mode FTP, which allows operation through firewalls and the Internet.

To download the latest firmware release, the following settings are required (but set by default):

- FTP username = **roving**
- FTP password = **Pass123**
- FTP filename = **wifly-GSX.img** (**VARIES BY DEVICE - DO NOT CHANGE THIS SETTING**)
- FTP directory = **./public** (this parameter cannot be modified)

- **NOTE:** To use FTP to upgrade the firmware, WiSnap module has to be associated to an Access Point with internet connectivity.

To update the firmware, issue the following command: **ftp upload <string>** (<string> is an optional filename, use to bypass the default firmware filename).

The ftp upload command will retrieve the file and switch the boot image to the new version.

<2.10> **ftp update**

<2.10> FTP connecting to 198.175.253.161

FTP file=30

.....

FTP OK.

- **NOTE:** FTP IP Address may vary. Check with SerialIO for most up-to-date credentials.

The previous firmware will become the backup image. Here is an example of what you should see after a successful update:

FL#	SIZ	FLAGS	
11	18	3	WiSnap_GSX-2.20
29	1	10	config
30	18	3	WiSnap_GSX-2.21
208 Free, Boot=30, Backup=11			

Note the module must be rebooted or power cycled to use the new firmware. To boot a different firmware use the following command: **boot image <num>** - sets the current boot image <num>. For example, to boot the previous image from above use **<2.20> boot image 11**

Set Boot Image 11, =OK

To upload your own firmware or config file to the module, change the stored FTP settings: See section 5.5 for more details on the FTP commands.

To upload your file, use following command:

- **ftp get <string>** - retrieves remote file with name <string>.

15 Ad Hoc Networking Mode

15.1 Infrastructure and Ad Hoc Comparison

There are two types of networks; infrastructure and ad hoc. Infrastructure networks, in which an access point links all Wi-Fi devices, are the most common. The access point keeps track of devices on the local network and directs IP packets. In many cases, the access point is also a router and forwards packets from the local network to the other networks and the internet. It is also very common for the access point to run a DHCP server, which tracks and assigns IP addresses.

Ad hoc networks are point-to-point networks in that each Wi-Fi device is linked directly to every other Wi-Fi device on the ad hoc network. There is no access point. All Wi-Fi devices on the ad hoc network participate in keeping the network alive and each keeps track of the other active devices on the network by sending and receiving beacon and probe packets. In most cases, IP addresses are assigned through automatic IP, although one of the Wi-Fi devices can be configured as a DHCP server.

- **NOTE:** The units support ad hoc networking, however, ad hoc mode has been replaced with soft AP mode. Ad hoc mode and soft AP mode are mutually exclusive and cannot operate at the same time. The support for these modes resides in separate firmware images loaded on the module. By default, the units are shipped with the ad hoc mode image to maintain backwards compatibility with existing applications.

15.2 Configuring Ad Hoc Mode

You can configure the module to setup an ad hoc network. This mode is useful for point-to-point communications. When in ad hoc mode the device appears like an access point with which other Wi-Fi devices can associate.

- **NOTE:** The module currently only supports the OPEN mode for creating ad hoc networks.

You can enable ad hoc mode via hardware or software commands.

15.3 Enable Ad Hoc Mode in Software

To enable ad hoc mode in software, you use the **set wlan** command with the **join**, **ssid**, and **chan** parameters. For example, type the following commands in command mode:

- **set wlan join 4**
- **set wlan ssid my_adhoc_network**
- **set wlan chan 1**

Turn off DHCP so that the module does not attempt to obtain an IP address from another device, and set the module's IP address and netmask. Because an automatic IP assignment fixes the first two bytes of the IP address, use 255.255.0.0 as the netmask so that other devices connecting to the module can be reached. You can also set the netmask to a smaller subnet if the other device's IP addresses begin statically at the same subnet as the ad hoc device.

- **set ip address 169.254.1.1**
- **set ip netmask 255.255.0.0**
- **set ip dhcp 0**

Save your configuration and reboot. The module will be in ad hoc mode.

The module can associate with an ad hoc network created by another device. Type the following commands:

- 1) **set wlan ssid my_adhoc_network**
- 2) **save**
- 3) **reboot**

To associate with an ad hoc network without saving the changes to the module's flash memory, use the **join** command, e.g., **join my_adhoc_network<cr>**. If the module was already associated with another network, you must first disassociate with it using the **leave** command.

If DHCP is enabled, the WiSnap device obtains IP address automatically when it associates with the ad hoc network. By definition, auto IP sets the first two bytes of the subnet to 169.254.xxx.xxx. The WiSnap device requires 2 to 3 seconds to resolve the IP address.

To set the IP address statically, disable DHCP and explicitly assign the IP address:

- **set ip dhcp 0**
- **set ip address 169.254.1.2**

You can confirm that the device has properly associated with the ad hoc network using the **ping** command:

- **ping 168.254.1.1 10**

You can associate with the ad hoc network from a computer by specifying the network name (and password, if required) in the operating system. For example, choose Control Panel > Networking and Sharing > Networking and Sharing Center. You can then view available networks and select the name of the WiSnap ad hoc network.

- **NOTE:** Once associated with the ad hoc network, Windows may require a few minutes to allocate an IP address. To work around this, assign a static IP address under Network Settings > TCP/IP > Properties.

Once your computer is associated with the ad hoc network, you can use the module's IP address to open a connection or connect using telnet as you would with an enterprise connection.

15.4 Scanning for Access Points in Ad Hoc Mode

The module supports ad hoc infrastructure network modes, but not simultaneously. Scanning for wireless networks is a function of infrastructure mode. Therefore, the module disables ad hoc mode before scanning.

With firmware version 2.22 and higher, the module can scan for networks while in ad hoc mode. Issuing the scan command temporarily disables ad hoc mode while the module is scanning. Ad hoc mode is restored automatically when the scan completes. If you are connected to the module over telnet, the scan result is sent over telnet and ad hoc mode is restored.

15.5 Enable Ad Hoc Mode in Hardware

To enable ad hoc mode using hardware, set GPIO0 high (3.3V) at power up. For the RN134 board, GPIO9 is on pin 1 on the jumper block (J2). For the RN174 board, GPIO9 is on the J6 connector. Upon power up with GPIO9 high, the WiSnap module creates an ad hoc network with the following settings:

SSID:	WiFly-GSX-XX, where XX is the final two bytes of the device's MAC address
Channel:	1
DHCP:	OFF
IP address:	169.254.1.1
Netmask:	255.255.0.0

With the ad hoc jumper in place, these settings override any current saved configuration settings.

16 Access Point Networking Mode

SerialIO WiSnap modules support several methods for configuring Wi-Fi networks. In addition to infrastructure mode, hot spot mode, and Ad-Hoc mode (2.36 firmware or earlier), modules with firmware version 2.45 can support access point (AP) mode. Currently, Access Point mode acts as a replacement to Ad-Hoc mode.

Access Point Mode provides many advantages over ad-hoc mode. In Access Point mode:

- The module creates a soft AP network to which Android devices (smartphones and tablets) can join. At the time this document was authored, android devices do not fully support ad-hoc networking.
- The module runs a DHCP server and issues IP addresses to up to seven clients, which is much faster than automatic IP in Ad-Hoc mode.
- iOS devices prioritize Access Points over Ad-Hoc networks.
- The module supports routing between clients

Before enabling AP mode, you must load firmware that supports it. You can get your version by typing **ver** while in CMD mode. You must change the version to 2.45 to use AP mode. You change the module's firmware image using the boot image *<value>* command. After you change the boot image, you **MUST** reset the module back to the factory defaults using the **factory RESET** and **reboot** commands. You can obtain the firmware images from the update FTP site. See "Upgrading Firmware via FTP" for instructions on how to download and install the firmware. Please note that initiating a **factory RESET** will result in "breaking" the embedded genuine WiSnap license and may cause compatibility issues with other SerialIO products.

The following sections describe how to use AP mode with WiSnap products, including configuring the module to act as an Access Point, enabling Access Point mode in hardware and software, and sending data to the module from a remote host.

16.1 Enabling AP Mode

There are two methods for enabling AP mode, hardware and software, as described in the following sections.

16.1.1 Enable in Hardware

To enable Access Point mode in hardware, hold GPIO9 high at 3.3 V and then reboot (or power cycle) the module. The module boots up in Access Point mode with the DHCP server enabled.

The table below displays the default Access Point Mode Settings:

Setting	AP Mode Default
SSID	WiSnapAP-XX, where XX is the last two bytes of the module's MAC address
Channel	1
DHCP Server	Enabled
IP Address	1.2.3.4
Netmask	255.255.255.0
Gateway	1.2.3.4

When the module boots, other Wi-Fi enabled devices (PCs, iPhones, iPads, Android Tablets, Android Phones, etc.) should be able to see the module when they scan for access points.

- **NOTE:** SerialIO recommends setting the WiSnap module as the gateway when creating a point- to-point network between devices. (Wi-Fi network only).

If devices such as smartphones and tablets (iPads, Android tablets, etc.) with a WAN connection associate to the soft AP network, SerialIO recommends setting the gateway to 0. This setting lets these smartphones route the data from Wi-Fi to the 3G or 4G WAN network.

16.1.2 Enable in Software

You enable Access Point mode in software using the **set wlan join 7** command. You can customize network settings such as the SSID, channel, and IP address in software to create a custom AP mode. For example, the following commands create a custom AP mode in software:

- 1) **set wlan join 7** - enable AP mode
- 2) **set wlan channel <value>** - specify the channel to create network
- 3) **set wlan ssid <string>** - set network ssid
- 4) **set ip dhcp 4** - enable DHCP server
- 5) **set ip address <address>** - specify the IP address
- 6) **set ip net <address>** - specify the subnet mask
- 7) **set ip gateway <address>** - specify the gateway IP
- 8) **save** - save settings
- 9) **reboot** - reboot the module in AP mode

After rebooting, the module is in Access Point mode.

16.2 Using Access Point Mode

The following sections describe how to use Access Point mode, including connecting to the module, checking for the last device connected over TCP, viewing associated devices, enabling the link monitor, and routing data between clients.

16.2.1 Connect to the Module

Once the module boots up in Access Point mode, any client device can associate with the network being broadcasted by the module. Once associated, the module's DHCP server assigns an IP address to the client device.

The default lease time is 1 day, i.e., 86,400 seconds. You can configure the lease time using the **set dhcp lease <value>** command, where **<value>** is the time in seconds. To view a list of devices associated with the module, use the **show lease** command. The command output is in the following format with commas delimiting the fields:

IP address assigned	Client MAC address	Remaining lease time (in seconds)	Host name
---------------------	--------------------	-----------------------------------	-----------

show lease command example output:

```
<2.45> show lease
1.2.0.10,1a:2b:3c:4d:5e:6f,86392,mydevice-12345678f
1.2.0.11,f6,e5,d4,c3,b2,a1,80153,*
1.2.0.12,00:00:00:00:00:00,0,
1.2.0.13,00:00:00:00:00:00,0,
1.2.0.14,00:00:00:00:00:00,0,
1.2.0.15,00:00:00:00:00:00,0,
```

- **NOTE:** In AP mode, the module can assign a DHCP lease to 7 clients. However, not all clients report the host name. In this case, the module reports that name as an asterisk (*).

Once a client is associated to the network, it can open a TCP connection to the module. After successfully opening a TCP connection, the client receives a ***HELLO*** message. The module prints ***OPEN*** on the UART, indicating an open TCP connection.

Check for the Last Connected Device over TCP

In some cases, it is beneficial to know the IP address of the last device that connected to the module over TCP or the last device to which the module connected over TCP. To find this address, use the **show z** command. This command does not survive a power cycle or reboot.

Upon power up, if no device is connected over TCP, the show z command returns **0.0.0.0**.

View Associated Devices

To see a list of devices associated with the module, use the **show associated** command. The command output is in the following format with commas delimiting the fields:

Connection number	Host MAC address	Received byte count	Transmitted byte count	Seconds since last packet received
-------------------	------------------	---------------------	------------------------	------------------------------------

show associated command example output:

```
<2.45> show associated
1,f0:cb:a1:2b:63:59, 36868,0,7
2,00:24:8c:31:e5:27:76168,0,2
3,98:4b:6b:e0:0f,1992,0,0
<2.45>
```

You can use the **Seconds since last packet received** output to check for stale connections.

Enable the Link Monitor

AP mode supports a link monitor feature. The Link monitor is a timer (in seconds) that checks to see if any packets are received from an associated device. When the timer expires, the AP module de-authenticates the client(s).

You enable the link monitor using the **set wlan link <value>**, where **<value>** is the link monitor timer in seconds.

- **NOTE:** It is recommended that you set the link monitor timer value to at least 300 seconds to avoid de-authenticating clients frequently.

Route Data between Clients

AP mode supports routing between clients. Clients can ping each other via the AP module and can also send data to each other over TCP and UDP.

- **set sys iofunc 0x70** - enables alternative functions
- **set wlan linkmon 60** - enables link monitor feature required for alternative functions

The link monitor feature must be enabled to turn on the alternative functions in soft AP mode only. The table below shows the GPIO alternative functions.

GPIO	Description
GPIO	Role in alternative function
GPIO4	High when the first client associates; low when all clients leave the network
GPIO5	WiSnap module can drive it high to open a TCP connection to a stored host. When the module drives GPIO5 low, it closes the TCP connection
GPIO6	WiSnap module drives it high when a TCP connection is open; low when TCP connection is closed

17 WI-FI Protected Setup (WPS)

Wi-Fi Protected Setup (WPS) is a standard for easy and secure establishment of a wireless home network. This standard was created by the Wi-Fi Alliance launched on January 8, 2007.


The goal of WPS protocol is to simplify the process of configuring security on wireless networks. The protocol is meant to allow home users who know little of wireless security and may be intimidated by the available security options to configure Wi-Fi Protected Access, which is support by all newer Wi-Fi certified devices (but not older Wi-Fi devices).

The most common mode of WPS is the Push Button Mode (PBC) in which the user simply pushes a button on both the access point and the wireless client (e.g., the WiSnap module).



The module supports the WPS feature in firmware version 2.28 and higher. To upgrade to the current firmware version and download the WPS application, refer to the WPS application note on the manufacturer's support page at http://www.rovingnetworks.com/Support_Overview.

- **NOTE:** Modules that ship with firmware version 2.28 or higher already have the WPS application. You can confirm whether your module has the application using the **ls** command.



Launching a WPS Application

There are two ways to invoke a WPS function:

- Using the **wps** command in the console.
- Using the ad hoc/factory reset pin (GPIO9).

To invoke a WPS function using the ad hoc/factory reset mode:

1. Enable the WPS function on GPIO9 using the **set system trigger 0x10** command. WPS on GPIO9 is disabled by default to avoid accidentally invoking the WPS function.
2. The WPS application is invoked when GPIO9 goes from low to high. You can enable this mode on the RN-134 and RN-174 boards by installing and removing the ad hoc/factory reset jumper.

When the WPS application exists, it reboots the module to associate with the WPS-enabled access point. If GPIO9 is high, the module boots in ad hoc mode. Care must be taken to drive GPIO9 low before the module reboots. A good indicator is the red LED on the RN-134 and RN-174 boards. When the LED flashes, indicating the module is scanning for a WPS-enabled access point, you should drive GPIO9 low.

By default, the WPS code prints messages on the UART as it scans channels, detects access points, and tries to complete WPS. You can disable these messages using the **set sys print 0** command.


Status LEDs during WPS Process

In WPS mode, the LEDs indicate activity:

- The red LED flashes while the module is scanning for WPS-enabled access points.
- The yellow LED goes on solid while negotiation is in progress with a WPS-enabled access point. If the process is successful, the WPS application quits and the module reboots.
- If the module is set to use the standard GPIO functions (i.e., not the alternate GPIO4 functions), the green LED blinks once per second. If the alternate GPIO4 function is enabled, the green LED goes high.

Scan Output Format Showing WPS-Enabled Access Point

The scan output shows access points that support the WPS feature. As shown below, access points that support WPS are listed with WPSPB in the security suites.




```

COM3 - Tera Term VT
File Edit Setup Control Window Help
scan
<2.27>
SCAN:Found 7
Num      SSID      Ch  RSSI  Sec  MAC Address      Suites
1         g2      01  -67  WPA2PSK 00:15:f9:38:bd:b0 AESM-AES 3104
2      SensorNet 01  -50  WPA2PSK 00:22:3f:6b:95:42 AESM-AES WPSPB 1100
3      roving1  01  -58  WPA2PSK e0:91:f5:57:a3:54 AESM-AES 3100
4      Belkin.40E9 06  -30  WPA2PSK 94:44:52:97:20:e9 AESM-AES WPSPB 1104
5      linksys  06  -76   Open  00:1e:e5:67:73:b1 WPSPB 104
6      default  06  -76   Open  00:18:02:70:7e:e8 WPSPB 2100
7      portthru 10  -52   Open  42:2b:fd:48:d4:8e Adhoc  200
  
```

If you press the WPS button on the access point and then perform a scan, the scan returns a **-A** to indicate the access point is in WPS active mode.

Scan Showing Access Points in WPS Active Mode



```

COM3 - Tera Term VT
File Edit Setup Control Window Help
scan
<2.27>
SCAN:Found 4
Num      SSID      Ch  RSSI  Sec  MAC Address      Suites
1      SensorNet 01  -52  WPA2PSK 00:22:3f:6b:95:42 AESM-AES WPSPB 1104
2      Belkin.40E9 06  -28  WPA2PSK 94:44:52:97:20:e9 AESM-AES WPSPB-A 1104
3      linksys  06  -72   Open  00:1e:e5:67:73:b1 WPSPB 104
4      default  06  -75   Open  00:18:02:70:7e:e8 WPSPB 2100
  
```

18 Analog Sensor Capability

The WiSnap module has 8 analog sensor inputs that can be driven between 0 to 1.2-V DC. You can sample the analog inputs and read digital value using the **show q <value>** command, where <value> is a decimal number representing the channel.

- **Warning: Driving these inputs above 1.2 V can permanently damage the module.**

Input voltage range: 0 - 1.2 V, however the A2D saturates at 400mV. Resolution: 14 bits = 12uV

Sampling frequency: 35us

Accuracy: 5% un-calibrated

The accuracy of each analog sensor reading can be offset by up to 5% due to variation from chip to chip. To improve accuracy it is recommend using a precision reference voltage on one of the analog inputs to calculate the offset. The offset will be the same for all analog inputs.

- For example:
 - drive precision 200mV reference on analog input 4.
 - read analog input 4 and compute the offset.

If you read 210mv you would know that the offset is +10mv. When you read input 5 you would subtract 10mv from the result. To read a sensor pin, send the following command:

show q <channel>

Channel is the analog sensor input from 0 to 7. The value for the analog sensor input is measured in microvolts and is returned as 8xxxxx. The 8 in front is a start marker.

You can also sample multiple channels by using a bit mask: **show q 0x1<mask>** where mask is a bit mask of the channels.

- For example, to read channels 0, 1, and 7, send the **show q 0x183** command.

The return values are the format: **8<chan0>, 8<chan1>, 8<chan7>\r\n**

Automatic sampling of sensor pins:

The sensor pins can be automatically sampled and data forwarded in two modes:

- 1) The UDP broadcast packet will contain the value of the samples.
- 2) In HTTP mode, the pin sampled data can be forwarded to a remote server

To enable the above modes, use the **set q sensor <mask>** command.

- For example, to sample all sensors inputs, use the **set q sensor 0xff** command.

Using the Built-In Sensor Power

WiSnap modules contain an onboard Sensor power pin, which is controlled by the **set q sensor <mask>** command. *<mask>* is a bit mask value that determines which sensor pins to sample when sending data using the UDP broadcast packet or the HTTP auto-sample function.

NOTE: In versions of firmware prior to 2.23, this command is named **set option sensor**. Firmware versions 2.23 and higher support the **set q power <value>** command. This command sets an 8-bit register with two 4 bit nibbles that automatically turns on the sensor power.

ON BOARD TEMPERATURE OPTION (RN-121-TEMP ONLY)

show q t

The return values are the format: **T=207\r\n** - this would be 20.7° C.

show q t 1 - enables automatic sampling and output once per second.

show q t 0 - turns off automatic sampling and output of temperature.

19 Default Configuration Settings

AD-HOC PARAMETERS

Parameter	Default
Beacon	102 (milliseconds) for ad hoc mode only
Probe	5 (seconds to look for beacons before declaring ad hoc is lost) for ad hoc mode only
Reboot	0, for ad hoc mode only

BROADCAST PARAMETERS

Parameter	Default
IP address	255.255.255.255
Port	55555
Interval	7 (seconds)
Backup address	0.0.0.0
Backup port	0

COMM PARAMETERS

Parameter	Default
Close string	*OPEN*
Open string	*CLOS*
Remote string	*HELLO*
Flush size	1420
Match character	0
Flush timer	10 (milliseconds)
Idle timer	0
Cmd char	\$

DNS PARAMETERS

Parameter	Default
IP address	0.0.0.0 dns1
Name	rn.microchip.com
Backup	86400 for soft AP mode only
Lease	

FTP PARAMETERS

Parameter	Default
Server address	0.0.0.0
File	Firmware only: wifly-GSX-<version>.img (RN131) wifly-EZX-<version>.img (RN171) Firmware and applications: wifly3-<version>.mif (RN131) wifly7-<version>.mif (RN171)
User	roving
Password	Pass123
Dir	public
Timeout	200
FTP mode	0x0

IP PARAMETERS

Parameter	Default
DHCP	ON (1 = enabled)
IP address	0.0.0.0
Net mask	255.255.255.0
Local port	2000

Gateway	0.0.0.0
Host	0.0.0.0
Remote port	2000
Protocol	2 (TCP server and client)
MTU	1524
Flags	0x7
TCP mode	0x0
Backup	0.0.0.0

OPTIONAL PARAMETERS

Parameter	Default
Device ID	WiFly-GSX
Join timer/WPA timer	1000
Replacement char	\$ (0x24)
Format	0x00
Password	"" (no password enforced)
Signal	0
Average	5

SYSTEM PARAMETERS

Parameter	Default
Sleep timer	0
Wake timer	0
Trigger	0x1 (SENS0 pin wakes up the device)
Auto connect	0
IOfunc	0x0 (No alternate functions)
IOmask	0x2F0 (for RN131) / 0x21F0 (for RN171)
IOvalue	0x0
Print level	0x1 (Print enabled)
Debug Register	0x0 (Unused parameter for future development. Leave at default value)
LaunchString	web_app

TIME SERVER PARAMETERS

Parameter	Default
Enable	0 (disabled)
Server address	64.90.182.55 (fixed to port 123 – SNTP protocol)
Zone	7 (Pacific time, USA)

UART PARAMETERS

Parameter	Default
Baudrate	9600
Flow	0 (disabled)
Mode	0
Cmd GPIO	0

WLAN PARAMETERS

Parameter	Default
SSID	roving1
Channel	0 (Automatic scan)
External Antenna	0 (Off – use on-board chip antenna for RN131 only)
Join mode	1 (Automatically scan and join based on SSID) for firmware version 2.36 (ad hoc mode) and lower 0 for firmware version 2.45 (soft AP mode) and higher
Authentication mode	OPEN
Mask	0x1FFF (All channels)
Rate	12 (24Mbit)
Linkmon	0

Passphrase	rubygirl
TX Power	0 (which implies 12 dBm. Applicable to RN171 module only)

String Variable Sizes

The tables below provide the string variable sizes for the listed parameters:

FTP PARAMETERS

Parameter	Value (Bytes)
file	32
user	16
pass	16
dir	32

WLAN PARAMETERS

Parameter	Value (Bytes)
ssid	32
phrase	64

DNS PARAMETERS

Parameter	Value (Bytes)
DNS host name	64
DNS backup host name	64

COMM PARAMETERS

Parameter	Value (Bytes)
open	32
close	32
remote	64
deviceid	32

19.1 Restoring Default configuration settings:

You can restore the default factory configuration settings in software and hardware.

- *Software*—In command mode, use the **factory RESET** command to restore the defaults. This command automatically loads the default settings and executes a **save** command. Next, send the **reboot** command so that the module reboots with the default configuration.
- *Hardware*—Set GPIO9 high on power up to arm the factory reset function. Then toggle GPIO9 five (5) times, which restores the configuration to the factory reset. GPIO9 is sampled at about 1 Hz; therefore, if you are using a CPU to generate the signal, make sure that GPIO9 transitions (high to low or low to high) are at least 1 second long.

You can specify a user configuration file as the factory reset settings. Prior to this firmware version only the hardcoded factory defaults would be restored. If you have stored a configuration file named **user**, the module reads it as the factory default instead of using the factory hardcoded defaults. If no **user** configuration file is present, the module uses the hardcoded factory defaults.

You create the **user** configuration file using the **save user** command, which saves the current configuration settings into a file named **user**.

Even if a user configuration file exists, arming and toggling GPIO9 7 times overrides the user settings and restores the module to the factory hardcoded defaults. This bypass mechanism allows you to restore the factory defaults in case a bad configuration is saved into the user file.

Issuing the **factory RESET** command while in command mode restores the module to a factory default state.

- **NOTE:** You must reboot the module or reset it for the new settings to take effect.

20 Boot-up Timing Values

The table below shows the boot-up timing values:

Function	Description	Time (ms)
Power up	Power up the time from reset high or power good to boot code loaded.	70
Initialization	Initialize ECOS	50
Ready	Load configuration and initialize application.	30
Join	Associate using channel = 0 (full channel scan, mask = 0x1FFF).	80
	Associate using channel = 0 (primary channel scan, mask = 0x421).	15
	Associate using channel = X (fixed channel).	5 – 20
Authentication	Authenticate using WPA1 or WPA2 (highly dependent on access point response).	50 – 250
Acquire IP	DHCP obtain IP address (highly dependent on DHCP server response time).	AP dependent

21 Supported 3rd Party Access Points

For information regarding putting your WiSnap device in Access Point mode, please see the section on [Access Point Networking Mode](#).

- **NOTE:** Access points that are set to MIXED mode (WPA1 and WPA2) may cause problems during association because some of these incorrectly report their security mode.

The WiSnap module does not currently support WPA2-Enterprise (radius server authentication, EAP- TLS)

The WiSnap should work with any standard Access Point. We have tested the WiSnap with the following access points:

- Cisco Aeronet series
- Linksys (both standard and openWRT Linux)
- Netgear WGR614 v8
- Netgear WGN54
- D-Link DIR-615
- Airlink 101
- Apple Airport Express
- Buffalo Networks
- AD-HOC MODE (Apple iPhone, Microsoft Windows PC with XP, Vista, Ubuntu Linux)

22 Command List

The tables below provide a listing of all available commands and their defaults. For more detailed information, refer to the “Command Reference.”

Set commands

Command	Default	Description
set adhoc beacon <value>	102	Sets the ad hoc beacon interval in milliseconds.
set adhoc probe <value>	5	Sets the ad hoc probe timeout in seconds (ad hoc mode only).
set adhoc reboot <value>	0	Sets the reboot timer.
set broadcast address <address>	255.255.255.255	Sets the address to which the UDP hello/heartbeat message is sent.
set broadcast backup <address>	0.0.0.0	Sets the secondary broadcast backup address.
set broadcast interval <mask>	7	Sets the interval (in seconds) at which the hello/heartbeat UDP message is sent.
set broadcast port <value>	55555	Sets the port to which the UDP hello/heartbeat message is sent.
set broadcast remote <port>	0	Sets the secondary broadcast port.
set comm \$ <char>	\$	Sets character used to enter command mode to <char>.
set comm close <string>	*CLOS*	Sets the ASCII string that is sent to the local UART when the TCP port is closed.
set comm idle <value>	0	Sets the idle timer value in seconds.
set comm match <value> <hex>	0	Sets the match character in hex or decimal.
set comm open <string>	*OPEN*	Sets the ASCII string that is sent to the local UART when the TCP port is opened.
set comm remote <string>	*HELLO*	Sets the ASCII string that is sent to the remote TCP client when the TCP port is opened.
set comm size <value>	64	Sets the flush size in bytes.
set comm time <value>	5	Sets the flush timer.
set dhcp lease <value>	86400	Sets the soft AP mode DHCP lease time in seconds.
set dns address <address>	0.0.0.0	Sets the IP address of the DNC server.
set dns backup <string>	rn.michrochip.com	Sets the name of the backup host for TCP/IP connections to <string>.
set dns name <string>	server1	Sets the name of the host for TCP/IP connections to <string>.
set ftp addr <address>	0.0.0.0	Sets the FTP server’s IP address of the FTP server.
set ftp dir <string>	public	Sets the starting directory on the FTP server.
set ftp filename <filename>	See description	Sets the name of the file that is transferred when issuing the ftp u command, where <filename> is the firmware image. Default firmware is: wifly-GSX.img (RN131) wifly-EZX.img (RN171)
set ftp pass <string>	Pass123	Sets the password for accessing the FTP server.
set ftp mode <mask>	0x0	Sets the ftp mode, where <mask> indicates active or passive mode. Default is passive.
set ftp remote <value>	21	Sets the FTP server’s remote port number.
set ftp time <value>	200	Sets the FTP timeout value, where <value> is a decimal number that is five times the number of seconds required.
set ftp user <string>	roving	Sets the user name for accessing the FTP server.
set ip address <address>	0.0.0.0	Sets the WiSnap module’s IP address.
set ip backup <address>	0.0.0.0	Sets a secondary host IP address.
set ip dhcp <value>	1	Enables/disables DHCP mode.
set ip flags <mask>	0x7	Sets the TCP/IP functions.
set ip gateway <address>	0.0.0.0	Sets the gateway IP address.
set ip host <address>	0.0.0.0	Sets the remote host’s IP address.
set ip localport <value>	2000	Sets the local port number.
set ip netmask <address>	255.255.255.0	Sets the network mask.
set ip protocol <flag>	2	Sets the IP protocol.

set ip remote <value>	2000	Sets the remote host port number.
set ip tcp-mode <mask>	0x0	Controls the TCP connect timers, DNS preferences, and remote configuration options.
set opt average <value>	5	Sets the number of RSSI samples used to calculate the running RSSI average.
set opt deviceid <string>	WiFly-XXX	Sets the configurable device ID, where XXX is GSX for the RN131 and EZX for the RN171.
set opt format <flag>	0x00	Sets the HTTP client/web server information.
set opt jointmr <value>	1000	Sets the join timer, which is the length of time (in ms) the join function waits for the access point to complete the association process.
set opt replace <char>	\$ (0x24)	Sets the replacement character you use to indicate spaces in the SSID and pass phrases, where <char> is a single character.
set opt password <string>	"" (no password required)	Sets the TCP connection password.
set opt signal <value>	0	Configures the threshold level for the RSSI value in infrastructure mode.
set q power <value>	0	Automatically turns on the sensor power.
set q sensor <mask>	0	Specifies which sensor pins to sample when sending data using the UDP broadcast packet or the HTTP auto sample function.
set sys autoconn <value>	0	Sets the auto-connect timer in TCP mode.
set sys autosleep <value>	0	Sets the auto-sleep timer in UDP mode.
set sys iofunc <mask>	0x0	Sets the I/O port alternate functions.
set sys launch_string <string>	web_app	Sets the application to launch when GPIO9 is high after power up.
set sys mask <mask>	0x20F0 (RN131) 0x21F0 (RN171)	Sets the I/O port direction.
set sys printlvl <value>	0x1	Controls the debug print messages printed by the WiSnap module on the UART.
set sys output <mask> <mask>	None	Sets the output GPIO pins high or low. The optional <mask> sets a subset of the pins.
set sys sleep <value>	0	Sets the sleep timer.
set sys trigger <flag> or <mask>	0x1	With this parameter setting, the module wakes from sleep state using the sensor input 0, 1, 2, and 3.
set sys value <mask>	0x0	Sets the default value of the CPIO pins' outputs upon power-up.
set sys wake <value>	0	Sets the automatic wake timer in seconds.
set time address <address>	64.90.182.55	Sets the time server address.
set time enable <value>	0	Tells the module how often to fetch the time from the specified SNTP time server in minutes.
set time port <value>	123	Sets the time server port number.
set time raw <value>	None	Allows you to set the RTC raw value from the console in seconds.
set uart baud <value>	9600	Sets the UART baud rate, where <value> is 2400, 4800, 9600, 19200, 38400, 57600, 115200, 230400, 460800, or 921600.
set uart flow <value>	0	Sets the flow control mode and parity.
set uart instant <value>	Not applicable	Immediately changes the baud rate, where <value> is 2400, 4800, 9600, 19200, 38400, 57600, 115200, 230400, 460800, or 921600.
set uart mode <mask>	0	Sets the UART mode register.
set uart raw <value>	Not applicable	Sets a raw UART value.
set uart tx <value>	Not applicable	Disables or enables the UART's TX pin (GPIO10), where <value> is 1 or 0.
set wlan auth <value>	0	Sets the authentication mode.
set wlan channel <value> <flag>	0	Sets the WLAN channel, where <value> is a decimal number from 1 to 13 representing a fixed channel and <flag> is the optional character i (meaning immediate).
set wlan ext_antenna <value>	0	Determines which antenna is active, where <value> is 0 (use the chip antenna) or 1 (use the U.FL connector).
set wlan fmon <value>	3600	Sets the soft AP mode link monitor timeout threshold for the associated client device.
set wlan id <string>	-	Reserved for future use.
set wlan hide <value>	0	Hides the WEP key and WPA passphrase, where <value> is 0 or 1.
set wlan join <value>	1 0	Sets the policy for automatically associating with network access points.
set wlan key <value>	Not applicable	Sets the 128-bit WEP key, where <value> is EXACTLY 26 ASCII chars (13

		bytes) in hex without the preceding 0x.
set wlan linkmon <value>	0 (disabled)	Sets the link monitor timeout threshold, where <value> is a decimal number representing the number of failed scans before the module declares AP is Lost and de-authenticates.
set wlan mask <mask>	0x1FFF (all channels)	Sets the WLAN channel mask, which is used for scanning channels with auto-join policy 1 or 2.
set wlan phrase <string>	rubygirl	Sets the passphrase for WPA and WPA2 security modes.
set wlan number <value>	0	Sets the WEP key number.
set wlan rate <value>	12	Sets the wireless data rate.
set wlan ssid <string>	roving1	Sets the SSID with which the module associates.
set wlan tx <value>	0	Sets the Wi-Fi transmit power, where <value> is a decimal number from 1 to 12 that corresponds to 1 to 12 dBm.
set wlan user <string>	-	Reserved for future use.

Get Commands

Command	Description
get adhoc	Displays the ad hoc settings.
get broadcast	Displays the broadcast UDP address, port, and interval.
get com	Displays the communication settings.
get dns	Displays the DNS settings.
get everything	Displays all of the configuration settings, which is useful for debugging.
get ftp	Displays the FTP settings.
get ip <char>	Displays the IP address and port number settings, where <char> is the optional parameter a. Using <char> returns the current IP address.
get mac	Displays the device's MAC address.
get option	Displays the optional settings such as the device ID.
get sys	Displays the system settings, sleep and wake timers, etc.
get time	Displays the time server UDP address and port number.
get wlan	Displays the SSID, channel, and other WLAN settings.
get uart	Displays the UART settings.
ver	Displays the firmware version.

Status Commands

Command	Description
show battery	Displays the current battery voltage, and is only applicable to Roving Network's battery-powered products, such as the RN370 and temperature sensors (ISENSOR-CB).
show connection	Displays the connection status in the hex format 8<XYZ>.
show io	Displays the GPIO pins' level status in the hex format 8<ABC>.
show net <char>	Displays the current networks status, association, authentication, etc., where <char> is the optional parameter n. Using the n parameter displays only the MAC address of the access point with which the module is currently associated.
show q <value>	Displays the value of the analog interface pin, where <value> is 0 to 7.
Show q 0x1 <mask>	Displays multiple analog interface values simultaneously.
show rssi	Displays the last received signal strength.
show stats	Displays the current statistics, packet RX/TX counters, etc.
show time	Displays the number of seconds since the module was last powered up or rebooted.

Action Commands

Command	Description
\$\$\$	Use this command to enter command mode.
apmode <bssid> <channel>	Creates a soft AP network.
close	Disconnects a CTP connection.
exit	Exits command mode.
factory RESET	Loads the factory defaults into the module's RAM and writes the settings to the standard configuration

	file. You must type the word RESET in capital letters.
join <string>	Instructs the WiSnap module to join the network indicated by <string>.
join # <value>	Use this command to join a network that is shown in the scan list, where <value> is the entry number listed for the network in the scan list.
leave	Disconnects the module from the access point to which it is currently associated.
lookup <string>	Causes the module to perform a DNS query for host name <string>.
open <address> <value>	Opens a TCP connection to <address>, where <value> is the port number.
ping <string> <value>	Pings a remote host, where <string> is a parameter setting and <value> is the number of pings. The default is 1 packet.
reboot	Forces the module to reboot (similar to a power cycle).
run	Runs an application using ASCII commands.
scan <value> <char>	Performs an active probe scan of access points on all 13 channels. The default is 200ms/channel.
sleep	Puts the module to sleep.
time	Sets the real-time clock by synchronizing with the time server specified with the time server (set time) parameters.

File I/O Commands

Command	Description
del <string> <value>	Deletes a file.
load <string>	Reads in a new configuration file.
ls	Displays the files in the system.
save <string>	Saves your configuration settings to a file.
boot image <value>	Makes a file represented by <value> the new boot image.
ftp update <string>	Deletes the backup image file, retrieves a new image file, and updates the boot pointer to the new image.
ftp <option> <filename>	<option> is: r = download the firmware only and do not set as boot image. u = download the firmware and set as boot image. c = clean the file system before performing firmware update.

23 Release Notes

23.1 Known problems

- Flow control—RTS may fail to de-assert quickly enough for some high-speed CPUs to stop sending data bytes correctly. For high-speed transfers at baud rates greater than 460,800, Roving Networks recommends limiting the RX data to the maximum Ethernet frame (1,460 bytes) and using a protocol to acknowledge that the remote host receives the data.
- The UART does not support odd or even parity; only no parity is supported.

23.2 Current Firmware features and fixes

As of version 4.41 11/25/2013

- Firmware update over UART using XMODEM 1K protocol.
- Added new optional parameters in FTP update and XMODEM:
 - ftp <option> <filename>
 - xmodem <option> <filename>, where <option> is
 - r = download the firmware only. Do not set as boot image (if firmware integrity checks pass).
 - u = download the firmware and set as booth image (if firmware integrity check pass).
 - c = clean the file system before performing firmware update over FTP or XMODEM 1K protocol. This will delete all the files on the Flash file system (including user defined configuration files) except the current boot image and the factory default boot image.

- Added WPA2-PSK personal security to soft AP mode. The soft AP commands are organized as follows:
 - set ap ssid <string>
 - set ap passphrase <string>
 - set ap link_monitor <time in seconds>
- Added a new command to invoke a temporary soft AP network (does not survive sleep or power cycle)
 - Apmode <ssid> <channel> <passphrase> where:
 - <channel> optional parameter. Sets the channel to create the soft AP network. Defaults to channel 1.
 - <passphrase> optional parameter, must be eight characters or more. Enables soft AP secure mode.
- Deprecated set wlan fmon <time in seconds> command
- Added updates to configuration of web server:
 - Added the ability to configure the module for infrastructure and soft AP mode.
 - Updated web pages for better display on mobile devices.
 - Added a timeout message to indicate the web server timed out.
- Removed the ability to handle special characters such as tab, carriage return, new line, and space on command line in web_app ONLY. All special characters are delimited with a backslash character (\) followed by a single character. The following special characters are supported:
 - \n = New line
 - \r = Carriage return
 - \s – Space
 - \t = Tab
- Added a new command to resolve the DNS name during ping:
 - Ping d<domain> - resolves the domain name and ping.
 - Example: ping dgoogle.com
- Added the ability to allow for scanning networks on channel 13 and 14.
- In the scenario of multiple access points having the same SSID and passphrase, added the ability to scan and pick the strongest access point during the association process.
- Fixed a bug where the **show rssi** command would occasionally return 0dBm.
- Fixed an issue where the **scan** command would return zero results in the first try.
- Fixed an issue that would occasionally cause the module to watchdog reset during the FTP firmware update process.
- Fixed an issue that would occasionally cause an “ERR-Malformed” error message during the FTP update process.
- Fixed an issue in the **show connection** command output where the prefix 8 was incremented in infrastructure mode. This has now been fixed and the output is 8XXX.
- Fixed an issue where the http request GET and POST parameters were being URL decoded too soon, resulting in errors.
- Fixed an issue where the **leave** command would not respond with the **Deauth** string over the UART.
- Fixed an issue where the module would occasionally get watchdog errors when configured in HTTP client mode.
- Changed the default IP address of the module from 1.2.3.4 to 192.168.1.1 in soft AP mode.
- Fixed an issue where the FTP close string would occasionally leave the module in a hung state.
- Fixed an issue where the module would send an invalid Deauth frame to the clients in soft AP mode.
- Fixed an issue that could cause the boot image to be invalidated under certain improper power up conditions.
- Fixed an issue that could cause the module to be bricked due to corruption in the config file caused during improper power supply during the process of saving the config file to Flash.
- Removed ad-hoc mode (**wlan join 4**)

As of version 4.00.1 04/19/2013

- Added a new feature to indicate the number of clients associated with the module in soft AP mode in the UART heartbeat message.
- Fixed an issue in which the GPIO4, 5, and 6 alternate mode was not working.
- Fixed an issue in which the link monitor was not working in infrastructure mode when auto join to a wireless network is disabled (**set wlan join 0**).
- Fixed an issue in which a null device ID was not reset to factory defaults when the factory reset command is issued.
- Fixed an issue in the FTP update process in which the module would watchdog when the module flash does not have enough free sectors.

- Fixed an issue in which the **show rssi** command was not working in infrastructure mode when auto join to a wireless network is disabled (**set wlan join 0**).
- Fixed an issue in soft AP mode wherein the **scan** command would not work the first time.
- Added stability to the FTP client mode.

As of version 4.0 03/27/13

- Added support for Multiple Image Format (**.mif**) files to download multiple images. This new file format contains the firmware image, applications such as WPS, EAP, web server, and supporting page files.
- The firmware image supports unpacking the files contained in the **.mif** package.
- Added a secondary UDP broadcast packet to send the UDP discovery message to a secondary server. The size of the secondary packet is 120 bytes (110 bytes of primary broadcast + 6 byte module's MAC address + 4 byte module's IP address).
- Added a new link monitor variable for soft AP mode. It is configurable via the **set wlan fmon <seconds>** command.
- Added a new configuration web server application onto the module for provisioning/configuring the module to join an infrastructure network.
- Added a new command to launch soft AP mode network: **apmode <bssid> <channel>**.
- Added a new command to launch different applications when GPIO9 is driven high, **set system launch_string <string>**.
 - Examples:
 - **set sys launch_string web_app** - launches web server (default)
 - **set sys launch_string wps_app** - launches WPS app
 - **set sys launch_string eap_app** - launches EAP app
- Added the command **run <string>** to launch individual applications.
 - Example:
 - **run wps**
- Deprecated the **wps** command.
- Fixed a bug wherein the UART would occasionally lock up upon performing the **factory RESET** command while telnet session was in progress.
- Fixed a bug in soft AP mode wherein the module would close the TCP connection upon another client being deauthorized.
- Fixed an issue with the link monitor in AP mode to correctly age out stale clients.
- Fixed an issue that would cause the module to crash due to a high-speed optimization error.

As of version 2.36/2.45 09/14/2012

- Firmware versions 2.36 and 2.45 are being shipped together. Version 2.36 supports ad hoc mode, while version 2.45 supports soft AP mode. All modules shipped with these firmware versions will run version 2.36 by default to maintain backward compatibility with previous firmware versions.
 - You can change the firmware image using the **boot image <value>** command. After you change the boot image, you MUST reset the module back to the factory defaults using the **factory RESET** and **reboot** commands. Please note that initiating a **factory RESET** will result in "breaking" the embedded genuine WiSnap license and may cause compatibility issues with other SerialIO products.
 - **Wifly_EZX-236.img**—Ad hoc mode firmware for RN-171
 - **Wifly_GSX-236.img**—Ad hoc mode firmware for RN-131
 - **Wifly_EZX-245.img**—Soft AP mode for RN-171
 - **Wifly_GSX-245.img**—Soft AP mode for RN-131
- In firmware version 2.36 (ad hoc version), the auto join feature is enabled to maintain backwards compatibility. In version 2.45, auto join is disabled and you must explicitly enable auto join mode using the **set wlan join 1** command.
- The firmware now supports parity with the **set uart flow** command.
- Added the **i** flag to the **set wlan channel** command, which changes the channel immediately. You can use this feature to go into AP mode without having to reboot or save the settings.
- In AP mode, de-authentication with the link monitor closes the TCP connection, flushes the UART buffer, and tries to clear stuck RTS flow control.

- In some cases flow control can get “stuck,” e.g., during a tcp_close or de-authentication in which the UART cannot transmit a TCP packet and is holding it. Added a fix to attempt to clear the buffer.
- In previous firmware, the associated status is always set even if no clients are joined. In version 2.45, the red LED correctly shows the status if there are no devices joined. If you use ALTERNATE IO for associated, it is high if there are 1 or more clients, and low if there are no clients.
- In AP mode, the module supports 7 connections (DHCP and AP).
- Fixed an issue with the ping command.

As of version 2.30 10/26/2011

- Added support for incorrect WPA modes, namely WAPv1 with AES encryption and WPAv2 with TKIP encryption.
- Added support for WEP shared mode.
- Increased FTP filename size to 64 bytes.
- Added a new reboot register in ad hoc parameters. This register is reserved for future development and should not be used. Please leave it to default values.
- Added a new debug register in the system parameters. This register is reserved for future development and should not be used. Please leave it to default values.

As of version 2.27 09/08/2011

- Added support for Wi-Fi Protected Setup (WPS) push button mode.
- Added support for WEP64 encryption.
- Added support for backup IP address.
- Added a new TCPMODE register to control TCP connect timers, force DNS and remote configuration.
- Added new bit in UART mode register (bit 5) in which replaces the <2.23>\r\n in console with the replace character.
- Fixed the FTP file “put” mode so it over rides HTTP mode. In version 2.23 if HTTP protocol is set and/or option format is set, extra data would be added to FTP put file data. This has been fixed in version 2.28.
- Fixed a bug where if the TCP_CLIENT mode is set, the module would randomly attempt outgoing connections.
- Fixed a bug in FTP data write mode whereby sometimes the *OPEN* status string came back over the UART before the file transfer was actually ready. This fix also improves the speed of FTP open in write mode, such that the *OPEN* will be faster.

As of version 2.23 04/03/2011

- Created new set of sensor commands: **set q sensor <mask>** and **set q sensor <value>**. Also, sensor power can now be configured and applied either only when sampling of sensor inputs occur or at power up and removed upon power down and sleep.
- Added a new FTP client mode to get and put files to a FTP server. Files retrieved from the server are sent over the UART and files created from the UART are stored on the FTP server.
- A new scan output format is implemented in addition to the default output format. This new microprocessor friendly format makes string processing of the scan output very easy.
- A new UART heartbeat feature is implemented to notify the embedded microprocessor of the state of the WiSnap module. The heartbeat message is sent over the UART when the WiSnap module is in data mode and not connected to any remote host.
- Fixed a bug in the **set uart instant <value>** command where the WiSnap module would not return an AOK over telnet. Now when this command is issued, it returns an AOK over telnet and does not exit command mode.
- Enabled scanning for wireless networks remotely when in ad hoc mode. When the **scan** command is issued, ad hoc is temporarily disabled and results of the scan are sent over telnet.
- The behavior of the auto connect timer has changed.
- Added the ability to set RTC from console.
- Added a feature wherein the module can be put to sleep using GPIO8.

- The firmware checksum the image (and compare to the stored values in the file) now before committing it to flash and updating the boot record after download. If the checksum fails firmware prints "UPDATE FAILED" and deletes the image.

As of Version 2.20 06/14/2010

- Passphrase now accepts up to 64 characters. A bug introduced in 2.19 causes the wlan passphrase to be truncated to 32 characters (making it impossible to enter a 32 byte HEX literal PSK).
- Fixed DHCP status when link to Access Point (AP) is lost. It was still reporting DHCP OK. It is now cleared and new DHCP session will start once AP link is reestablished.
- Fixed a bug where UDP receive becomes disabled (no packets are received) if AP-LOST and then re-established.
- Improved handling of AP disconnect, and AP link lost due to linkmon timeout or other disconnect
- If TCP connection was active, connection could be in hung/incorrect state, and once AP is regained, in some cases, this would not recover. This has been fixed in this version. Refer to section **set ip flags <value>** for more information.
- Added new setting to the UART mode - **set uart mode 0x10**.
- Disabled the auto-join feature when in command mode. Auto-join causes WiSnap to become unresponsive to \$\$\$ or commands during the period when auto-joining is failing due to non-existent AP, making it hard to process or interpret commands. Once command mode is exited, auto-join will re-enable.
- There are new levels of print out diagnostics that can be enabled/disabled with the **sys print** variable.
- Ability to add prefix to HTML client post, specifically the ability to append **&id=** and **&rtc=** in the HTML message.

As of Version 2.19 3/05/2009

- Improved performance of the UART receiver. UART is now reliable at up to 460Kpbs with RTS flow control.
- Created UART data trigger mode, which will automatically make a TCP/HTTP connection based on received UART data. **Set uart mode 2** to enable this mode.
- Added time stamping option to both UDP and TCP packets. 8 byte RTC counter is appended.
- DHCP client now inserts the DEVICEID string into the HOST name when requesting a DHCP lease. This string is displayed by most routers and DHCP servers in their lease tables.
- **show net n** command returns the MAC Address of the Access Point currently associated.
- **get i a** command returns only the IP address of the WiSnap.
- **show network** added a response "Boot=<time in ms>" which displays the total time in milliseconds that was required to be ready on the network (associate and get IP address). This time is also added to the UDP broadcast packet at byte location 92.
- Added a number of HTTP commands for posting data to a web server. See Section 12.

As of Version 2.15 10/15/2009

- Fixed a problem where the first UART RX character received on power up is received but does not sent until receipt of 2nd character.
- Fixed a problem with some APs that violate Wi-Fi specifications by not responding to WPA authentication within 250ms. The **set option jointimer xxxx** command, which specifies the timeout in ms for a **join** now also applies to the WPA timeout. The default is now 1000ms or 1 second. NOTE: some APs require up to 1500ms to respond.
- When connected over TCP, and the AP disappears or WiSnap loses association, the WiSnap will now close the connection. The *CLOS* response will now appear when the connection is terminated by the WiSnap. NOTE: This may require the use of the **set comm idle xx** setting to monitor the TCP connection, and force a TCP disconnect when no data is flowing due to lost association.
- Link monitor - The command **set wlan linkmon x** is now used to monitor the state of the association to the AP. The AP is scanned once per second, and if x consecutive scans fail, the WiSnap declares "AP is lost" sets the interface to down state, and enters the association process. Previously the WiSnap would not detect that the AP association was lost until the AP became available again, or the WiSnap was power cycled or rebooted.

- AD-HOC mode - The command **set ad-hoc probe x** is now used to set a threshold for the number of consecutive missed probe responses allowed before declaring "AD-HOC is Lost" and setting the network interface to be down. Default is 5 probes. A setting of **set ad-hoc probe 0** will disable this function. Some Ad-hoc stations do not reliably respond to probes and so this value higher avoids intermittent loss of connectivity.
- DHCP cache - The **set ip dhcp 3** command is now used to enable DHCP address caching. Once caching is turned on, the initial DHCP settings are stored in NVRAM. This is most useful in battery systems, when using the sleep mode. Upon waking from sleep, as long as the DHCP lease time is still valid and the WiSnap is associated to the same AP, DHCP caching does not survive a power cycle or usage of the hardware reset pin.
- ARP table cache - The **set ip flags 0x20** command is now used to enable ARP table caching. Once caching is turned on, any ARP table settings are backed up to NVRAM before sleep. Upon waking from sleep, the ARP cache is loaded. ARP table caching does not survive a power cycle or usage of the hardware reset pin.
- DNS host address cache - The **set ip flags 0x10** command enables DHCP address caching. Once caching is turned on, the initial DHCP settings are stored in NVRAM. This is most useful in battery systems, when using the sleep mode. Upon waking from sleep, as long as the DHCP lease time is valid and the WiSnap is associated to the same AP, DNS caching does not survive a power cycle or usage of the hardware reset pin.
- UART break detect enables sleep - The command **set uart mode 8** enables break detection on the UART RX pin. Once Break is detected (a consistent low value on RX pin), WiSnap waits for the UART RX pin to return to a high value before going to sleep.
- UART NOECHO mode - The command **set uart mode 1** is now used to disable echoing of RX chars while in command mode. This is useful when embedded controllers are used to send commands to the module. NOTE: For consistency, the command prompt response <2.xx> now also contains \r\n appended string when in this mode.

As of Version 2.12 9/17/2009

- Fixed problem with some newer 802.11n - association attempts cause module to crash/reboot. (Such as Linksys WRT160NL)
- Fixed problem with send on match character i.e. **set comm match <char>**. Match char is now operational.
- During an open TCP session, a second incoming connection would be accepted. Second connection is now accepted but then immediately closed.
- Hardware flow control is now supported. To enable, use the **set uart flow 1** command.
- DHCP renew and rebind is fully supported. Previously, DHCP renew/rebind would update IP settings, and if a TCP session was active it would enter a hung state. TCP connections now survive a DHCP renew/rebind.
- TCP connection password - This optional password is enabled with the command **set opt pass <string>**. Incoming connections will be challenged and the stored password must be matched or the connection will be closed.
- UART instant baud rate - The **set uart instant <rate>** command immediately changes the baud rate. This is useful when testing baud rate settings, or switching baud rate "on the fly" remotely while connected over TCP.
- Analog interface commands - The **show q** command will now enable and show the digital value of the analog interface pins. See section 18.

Version 2.11 9/8/2009 – Limited release (please update to 2.12 or later) As of Version 2.10 8/14/2009

- Added a 250ms guard band in parsing of \$\$\$\$. The module now looks for three \$\$\$, and only three \$\$\$ within a 250ms period with no additional characters following for 250 ms. Do not send \cr or \lf after the \$\$\$.
- Fixed problem with UART dropping data. In cases with large data transfers (>100KB) the UART would become over whelmed and drop data.
- We no longer pass serial data received into the UART back over telnet when in remote command mode.
- User specified default configuration - You can now specified a USER configuration as the factory reset settings. The function of PIO9 has been changed slightly. See section 19.1.
- Configurable Device ID – There is now an additional user programmable device ID that can be used for storing serial numbers, product name, device type or other information. The device ID is part of the broadcast "hello" UDP message that the module sends out to identify itself. Use the command **show deviceid** to display the current setting. For more information on using this command see the "set optional" section command.
- UDP broadcast packet – By default the WiSnap module now sends out a UDP broadcast to 255.255.255.255 on port 55555 at a programmable interval. The broadcast address, port and interval are set using the set broadcast commands. See section 11.

Known Issues

- WiSnap Module has trouble associating with some 802.11.n access points. The module will crash and reboot repeatedly. We have seen this behavior with Linksys and Dlink router/access points. If you disable the .n capability on the router the module will associated correctly.
- Flow control is not functional.

Current Firmware Version 2.09 7/10/2009

- Sleep mode was drawing 70uA instead of the expected 4uA due to an oscillator that was not disabled before going to sleep. Refer to the WISNAP datasheet for the proper low-power hardware configuration.
- Fixed closing of TCP port on TCP RESET. Previously the module was not handling remote TCP reset correctly and would disconnect which resulted in a printout of ERR= -5, TCP port was not closed properly.
- Fixed clearing and setting of strings in several **set** commands. In these cases the strings could be erased, but not reset.
 - **set comm remote**
 - **set comm open**
 - **set comm close**
 - **set dns name**
 - **set dns backup**
- Removed extra character in UART output. Previously the module would insert an extra "\r" character when '\n' appears in data stream.
- Added the **get everything (get e)** command to display all configuration settings.
- Fixed the alternate I/O functions to allow connection based on PIO5. The manual has been updated to include a much better description of this functionality. See section 10.5.

As of firmware version 2.08 6/08/2009

- Connecting out an IP address does not use the DNS and backup DNS if the connection to the primary IP address fails. Connecting using DNS if the IP address if 0.
- UART hardware flow control not yet functional.
- TCP_NODELAY added as default. This improves performance as the stack no longer waits for each TCP packet to be ACK'ed, (since many Microsoft systems only ACK every OTHER packet).
- Set ip proto is now a bitmask. It is possible to have both UDP and TCP bits set. If TCP enabled, UART RX data will be forwarded via TCP if a connection exists. Otherwise, data will forward over UDP (if UDP bit is set).

As of firmware version 2.07 6/04/2009

- **set wlan antenna <0 or 1 >** command has been changed to **set wlan extant <0 or 1 >**.
- **set wlan auth <value>** command has been added.
- **set wlan hide** will hide the WEP key or WPA passkey. To unhide, you set key or passphrase again.
- **set ip proto 8** - TCP client mode, (no listen server) only outbound connections can be made.
- Ad-hoc mode client associates properly.
- You can now enter the WPA passkey after setting the SSID. Previously the pass key had to be entered first for the security hash to be correctly created.
- Auto join now stops after 3 retries.
- **show net** now displays the Wi-Fi TX rate, and correctly displays authenticated state and shows authentication mode that was used.
- **ping h** will ping the stored host address. If no host address stored, will attempt to use the DNS hostname.

- **ping i** command added to ping a known Internet server (www.neelum.com) by first resolving the address, proving that DNS is working and then pinging the server. This proves the device has internet connectivity.
- UDP secure mode will only forward packets to the UART that match from the host address. TCP secure mode will only allow connection from and IP that matches host address.

As of firmware version 2.06

- Web server interface is not available – Configuration over telnet and the UART.
- UART flow control is not functional – The module may drop data at high data rates.
- Sensor pins for reading analog signals are not supported.
- Wake on UART RXD or CTS is not working on current revision REV2 of the WiSnap SuRFBoard.
- The fast- autosleep timer for UDP mode is not implemented.

Fixes since firmware version 2.05

- Configuration over Telnet not functional.
- Error checking the correct number of parameters.

Copyright © 2011 SerialIO.com. All rights reserved.

The Bluetooth trademark and logo are registered trademarks and are owned by the Bluetooth SIG, Inc. All other trademarks are property of their respective owners.

SerialIO.com reserves the right to make corrections, modifications, and other changes to its products, documentation and services at any time. Customers should obtain the latest relevant information before placing orders and should verify that such information is current and complete.

SerialIO.com assumes no liability for applications assistance or customer product design. Customers are responsible for their products and applications using SerialIO.com components. To minimize the risks associated with customer products and applications, customers should provide adequate design and operating safeguards.

SerialIO.com products are not authorized for use in safety-critical applications (such as life support) where a failure of the SerialIO.com product would reasonably be expected to cause severe personal injury or death, unless officers of the parties have executed an agreement specifically governing such use.