


Setting up the Scanfob 2006 with special prefix characters before data.
(Settings will apply to ALL barcode symbologies)


Remove prefix character (will send only data)



Prefix character STX – Start of Text



Prefix character HT – Horizontal Tab



Setting up the Scanfob 2006 with special suffix characters after data.
(Settings will apply to ALL barcode symbologies)


Remove suffix character (will send only data)



Suffix character CR – Carriage Return



Suffix character HT – Horizontal Tab



Suffix character TAB – Tab key

