

SCANFOB® 6000, PX20

Set Scanner Read Mode



Scan Always

Scan "Scan Always" and the Scanfob® PX20 engine will be in 'watching mode'. When it detects light change it goes into active scanning mode.



Press to Scan

Scan "Press to Scan" and the Scanfob® PX20 engine will scan only when the scan button is pressed (default mode)



One-button mobile solutions
with endless possibilities

.....
715 Discovery Blvd.
Suite 510
Cedar Park, TX 78613